

## Use and Care Manual

**Product Name:**8-Piece Outdoor Wicker Round Sofa Set

## Introduction

Thank you for purchasing our 8-Piece Outdoor Wicker Round Sofa Set. Designed for all-weather use, this set features a half-moon sectional configuration, a rectangular coffee table, PE rattan construction (water-resistant and UV-protected), and movable cushions for enhanced comfort. Follow this manual to ensure safe use, optimal performance, and long-lasting durability.

## 1. Safety Precautions

**WARNING:**Always prioritize safety when assembling, using, or maintaining the furniture.

- **Assembly:**Two people are recommended for assembly to avoid injury or damage. Use only the provided tools and hardware. Do not overtighten screws, as this may crack the rattan or frame.
- **Weight Limit:**Each seat supports a maximum weight of 250 lbs (113 kg). Do not exceed the total weight capacity of the sectional set (refer to the product label for details).
- **Weather Safety:**Do not use the furniture during extreme weather (e.g., heavy rain, strong winds, snowstorms, or temperatures below -10°C/14°F). Secure the set or move it indoors during storms to prevent tipping or damage.
- **Fire Hazard:**Keep the furniture away from open flames, grills, or high-heat sources (e.g., fire pits) to avoid melting the rattan or igniting cushions.
- **Sharp Objects:**Avoid placing sharp or abrasive items on the rattan or cushions, as they may scratch or tear the material.

## 2. Components List

Your 8-piece set includes the following components (exact quantities may vary by model; refer to the package checklist for confirmation):

- 2 × Half-Moon Curved Sofa Sections
- 2 × Armless Single Sofa Chairs
- 1 × Rectangular Coffee Table
- 5 × Removable Seat Cushions (water-resistant fabric)
- 5 × Removable Back Cushions (water-resistant fabric)
- Hardware kit (screws, washers, Allen wrench)

## 3. Assembly Instructions

1. **Unpack & Inspect:**Remove all components from packaging and check for damage or

missing parts. Contact customer service immediately if items are missing or defective.

**2. Assemble Frame:**

- Connect the half-moon sectional sections and armless chairs using the provided screws and Allen wrench. Align pre-drilled holes and tighten screws until snug (do not overtighten).
- Attach the coffee table legs (if applicable) following the same method.

**3. Place Cushions:** Once the frame is assembled, arrange the movable seat and back cushions on the sofa sections and chairs.

## 4. Usage Guidelines

- **Intended Use:** For outdoor leisure only (e.g., patios, decks, gardens). Do not use as storage, step stool, or for commercial purposes.
- **Cushion Care:** Cushions are water-resistant but not fully waterproof. After rain, wipe cushions with a dry cloth or remove them to air-dry to prevent mold. Avoid leaving cushions in standing water.
- **Weight Distribution:** Distribute weight evenly across seats to prevent tipping or stress on the frame.

## 5. Care & Maintenance

### PE Rattan Frame

- **UV Protection:** The PE rattan is UV-treated to resist fading, but prolonged exposure to direct sunlight may cause minor color changes over time. For extended lifespan, position the set in a shaded area or use a patio umbrella.
- **Regular Inspection:** Check the frame quarterly for loose screws, rattan fraying, or damage. Tighten screws as needed with the provided Allen wrench.

### Movable Cushions

- **Water Resistance:** Cushions feature water-resistant fabric, but the inner foam may absorb moisture if saturated. After rain, shake off excess water and air-dry thoroughly.
- **Stain Prevention:** Treat spills immediately with a damp cloth. For oil-based stains, use a mild detergent (e.g., dish soap) and warm water.

## 6. Cleaning Instructions

### PE Rattan Frame

- **Routine Cleaning:** Use a soft-bristle brush or cloth to remove dust and debris. For deeper cleaning, mix mild soap (e.g., dish soap) with warm water, gently scrub the rattan, then rinse with a garden hose. Allow to air-dry completely before use.
- **Avoid Harsh Chemicals:** Do not use bleach, abrasive cleaners, or pressure washers, as these may damage the rattan's finish.

### Cushions

- **Surface Cleaning:** Wipe cushions with a damp cloth and mild soap. For stubborn stains, spot-clean with a soft brush.
- **Deep Cleaning (if removable covers):** Remove cushion covers (check for zippered closures). Machine wash on a gentle cycle with cold water and mild detergent. Do not bleach or use fabric softener. Air-dry covers flat (avoid direct sunlight to prevent shrinking/fading). Reattach covers once fully dry.
- **Non-Removable Covers:** Hand-wash with mild soap and water, then air-dry.