

MANTEL

MODEL

X5021-2CHR

X5021-2MAH


X5021-2TEK

X5021-2WHT













X5021-2BLK

X5021-2WAL




X5021-2GRY



PACKAGE CONTENTS

	A		B		C
	D		E		F
	G₁		G₂		H
	I		J		K

HARDWARE CONTENTS

	AA		BB		CC		DD		EE		FF
Bolt Qty. 20		Metal Connector Qty. 20		Handle Qty. 2		Screw Qty. 24		Cabinet Door Hinge Qty. 4		Screw M5x25 Qty. 2	

PACKAGE CONTENTS


PART	DESCRIPTION	QTY.	PART NO.
A	Top Panel	1	
B	Top Shelf	1	
C	Left Side Panel	1	
D	Right Side Panel	1	
E	Left Inner Panel	1	
F	Right Inner Panel	1	
G1	Lower Back Panel	1	
G2	Lower Back Panel	1	
H	Base	1	
I	Upper Back Panel	1	
J	Left Door	1	
K	Right Door	1	
AA	Bolt	20	
BB	Metal Connector	20	
CC	Handle	2	
DD	Screw	24	
EE	Cabinet Door Hinge	4	
FF	M5x25 screw	2	

Some parts and specifications may change without notice.


Carefully remove all pieces from the carton and make sure that you have all parts listed (refer to parts list on page 2-3).

PACKAGE STEPS

1.




2.




PACKAGE STEPS

3.




4.




PACKAGE STEPS

5.




6.




PACKAGE STEPS

7.




8.




PACKAGE STEPS


9.




10.




11.




12.




13.




14.




15.




16.




17.



18.



19.



20.

