



How do I use Kut-it?

Simply place the Kut-it tool over the existing sprinkler head and hand turn counter-clockwise until the tool hits the top of the head. Pull up and remove the turf cup divot. This operation can also be performed with a drill/driver gun or ratchet to make the turf removal effortless. If you wish to remove the cap to replace the internals of the sprinkler, simply flip the tool over and place the tool over the top of the sprinkler (any rotor or any spray) and turn counterclockwise and the tool will unthread the cap.

