This product is an electrical submersible pump with a water-resistant lamp. When used with the supplied 12V AC-transformer, this product may be used safely in the manner described in this manual. Handle with care to ensure that the lamp always remains submerged when in use at the risk of product damage or personal injury.

Part pieces:

Buddha body Ball Transformer Pump body Led light

Warnings before you assemble:

- 1. The pump body and the LED light that is directly connected to the electrical cord are to come in contact with water only.
- 2. Under no circumstances should the plug-in transformer come into contact with water.
- 3. Do not plug-in or use this product if any part of it appears to be damaged or operates abnormally. Have the product examined and repaired, if necessary, examined by a qualified electrician.
- 4. Make a "drip loop" on the electrical cord connecting the pump to the transformer plug by letting a portion of the cord hang lower than either the pump or the transformer.
- 5. Do not let the pump run when not submerged in water. Doing so may damage the pump. Always submerge the pump first, and then plug in the transformer.
- 6. Make sure to ensure excess power cords are stowed so as to avoid tripping.
- 7. Operate the unit only under constant adult supervision and monitoring. Keep the unit unplugged when not under direct observation.
- 8. Use this product indoors only.

Instructions:

- 1. First, connect the pump body and the LED light to the plug-in transformer and place the LED light inside the Buddha's body.
- 2. Then, connect the other end of the pump body to the tube inside the Buddha's body. Make sure the tube and the pump body leaves no gap and leave the pump body inside the Buddha's body
- 3. After inserting the parts and placing them into the Buddha's body, please reread the warnings and safety instructions for safety purposes and proceed to the next step.
- 4. Next, place as much water inside the Buddha's body. Make sure there's enough water inside the body because not enough water will cause it to not work properly.
- 5. Place the ball in front of the Buddha on top of the Buddha's hands.
- 6. Finally, plug-in the transformer. The LED light should light up and the motor from the pump body should be running. If the ball is not turning, wait for couple minutes for the pump to absorb the water.

7. If the motor is not working, make sure to turn on the switch on the pump body.

Maintenance:

- 1. Use this pump with distilled water only. Mineral build up from tap water or water from other source can ruin the pump.
- 2. No maintenance is necessary when this product is used in the manner described in this manual.
- 3. If debris is caught in the intake vents of the pump, disconnect the pump from any power sources and rinse the pump under clean running water.