

Clean all detachable parts after each use in hot, soapy water.

Wipe exterior surface with a soft damp cloth to remove stains. Never use scouring agents or harsh abrasive cleaners.

Decalcifying is recommended every 2–4 months using vinegar.

FOR MORE INFORMATION PLEASE USE INSTRUCTION MANUAL

No