

MODEL:IG10600119-1012



OWNER'S MANUAL

10'x12' Cedar Wood Hard Top Pavilion

TABLE OF CONTENTS

ASSEMBLY GUIDE.....02

USING YOUR PRODUCT.....05

February 26, 2025

QUESTIONS?

 E-mail: support@modernshade.org


























 Toll Free: 1-888-666-3070

 Mon-Fri: 9am--- 5pm PST.

CONTACT CUSTOMER SUPPORT BEFORE RETURNING PRODUCT TO RETAILER.



ASSEMBLY GUIDE

PARTS LIST

A1 Post 1 (2pieces) 	A4 Post 4 (1piece) 	A5 Post 5 (1piece) 	A7 Post 7 (1piece) 	A8 Post 8 (1piece) 	B1 Front Left Beam 1 (1piece) 
P0010003901	P0010004001	P0010004101	P0010004201	P0010004301	P0040007801
B4 Front Right Beam 4 (1piece) 	M1 Rear Left Beam 1 (1piece) 	M4 Rear Right Beam 4 (1piece) 	N1 Side Beam 1 (1piece) 	N3 Side Beam 3 (1piece) 	N5 Side Beam 5 (1piece) 
P0040007901	P0040008001	P0040008101	P0040008201	P0040008301	P0040008401
N7 Side Beam 7 (1piece) 	C1 Support Bracket 1 (2pieces) 	C2 Support Bracket 2 (2pieces) 	C3 Support Bracket 3 (1piece) 	C4 Support Bracket 4 (1piece) 	C5 Support Bracket 5 (1piece) 
P0040008501	P0050003901	P0050004001	P0050004101	P0050004201	P0050004301
C6 Support Bracket 6 (1piece) 	D Foot Cover (4pieces) 	E Foot Base (4pieces) 	F1 Roof Plates 1 (6pieces) 	F3 Roof Plates 3 (6pieces) 	F4 Roof Plates 4 (6pieces) 
P0050004401	P0020000304	P0030000304	P0130006101	P0130006201	P0130008001
G1 Roof Rib 1 (4pieces) 	G2 Roof Rib 2 (4pieces) 	H1 Connector 1 (4pieces) 	H2 Connector 2 (4pieces) 	H3 Connector 3 (1piece) 	H4 Connector 4 (1piece) 
P0090009901	P0090010001	P0060006501	P0060006601	P0110003001	P0110003101
H5 Connector 5 (2pieces) 	J1 Roof Rib Support 1 (3pieces) 	J2 Roof Rib Support 2 (2pieces) 	K1 Top Beam Support 1 (5pieces) 	K2 Top Beam Support 2 (3piece) 	K3 Top Beam Support 3 (6pieces) 
P0110003301	P0050004501	P0050004601	P0090010101	P0090010201	P0090010301

Outdoor Structure anchoring guide for anchoring gazebo to wood or concrete: If step 31, on page 20 in the assembly instructions is not properly completed , this will void the warranty.

WARNING! If your gazebo is not properly anchored, damage could occur. It is highly recommended for maximum safety that you mount and secure to wood or concrete footers. This is far better and safer than using ground stakes. The following are some examples of how to mount the structure to wood or concrete surfaces. Refer to local building codes or consider consulting a licensed contractor for assistance in the anchoring of this product.

WOOD	CONCRETE
	
Anchors should be drilled into joists or reinforced blocking (not only deck boards).	Pre-drill holes for appropriately sized concrete anchors.
	
Recommended Hardware: Expansion Bolt	Recommended Hardware: Expansion Bolt

If digging for foundation, please double check for possibility of any underground utilities such as gas, telephone, cable or sprinkler lines. Refer to your local building and city codes, ordinances, neighborhood covenants, or height restrictions regarding this type of structure for guidance on acceptable installation requirements.

CAUTION

DO NOT climb or walk on roof for any reason.

- Our components are intended for privacy, decorative and ornamental use only.
- Product is NOT INTENDED for the following:
 - A safety barrier to prevent unsupervised access to pools, hot tubs, spas or ponds.
 - As load bearing support for a building, structure, heavy objects or swings.
 - Used in structures that trap wind, rain or snow that would create extra load on the product.
 - Accumulated snow must be removed from roof.
 - DO NOT climb or walk on roof for any reason.

LIMITED WARRANTY

We warrants this product against defects in materials and workmanship for a period of one (1) year from the original date of purchase. To the extent any such defects occur, our products will send the appropriate replacement part(s) at no charge.

This warranty does not cover:

- Inspection costs or labor for replacement of any defective parts);
- Incidental or consequential damages;
- Cosmetic defects which DO NOT affect performance;
- Normal wear and tear;
- Damage due to vandalism; acts of nature, including but not limited to wind, storms, hail, floods;
- Improper assembly, installation, or use;
- Discoloration or fading of the finish as a result of exposure to chemicals, spills, pool or salt water
- Corrosion/ rust.

Your product has been designed for safety and quality. Any modifications made to the original product could compromise its structural integrity or function, and could lead to product failure or personal injury. As such, modifying this product voids any and all warranties.

This product is warranted for RESIDENTIAL USE ONLY, and is not for commercial, contract or other non-residential purposes. Products disclaims all other representations and warranties of any kind, express or implied.

The warranty applies to the original purchaser and is non-transferable. It does not apply to purchases of display models, or when the product is sold on clearance or "as is".

We makes no warranty whatsoever in respect to accessories or parts not supplied with it. This warranty shall apply only within the boundaries of the United States of America and Canada. This warranty gives the original purchaser specific rights, and the original purchaser may also have other rights, which vary from state to state.

