Winter Air-Flow Selector







The Turbine Boss™ exhausts attic moisture in winter, while saving energy. It's Easy. Simply choose the 'winter ventilation rate' before installing.



Recommended: Select 20% Winter Air-Flow...

turbine suction is **reduced 80%** during cold temperature.

- See Instruction -