

Dining Chair Use and Care Manual

Introduction

Thank you for choosing our dining chair. This chair is designed with a balance of comfort, style, and durability to suit your dining space. Please follow the guidelines below to maintain the quality and longevity of your chair.

Assembly Instructions

1. Unbox all components carefully.
2. Follow the provided assembly instructions to assemble the chair securely. Ensure all screws, bolts, and parts are firmly tightened.
3. Once assembled, check that the chair is stable before use.

Usage Guidelines

- This chair is designed for **indoor use only**. Avoid placing it in areas exposed to direct sunlight, excessive heat, or moisture to prevent damage.
- **Weight capacity:** Do not exceed the recommended maximum weight limit of 250 lbs (113 kg).
- Use the chair on a **level surface** to ensure safety and stability during use.
- Ensure children use the chair under adult supervision.

Care Instructions

- **Cleaning:** Wipe the chair regularly with a soft, damp cloth. For fabric upholstery, spot clean with mild detergent and water. For wood or metal parts, use a non-abrasive cleaner.
- **Avoid harsh chemicals:** Do not use bleach, abrasive sponges, or other harsh chemicals, as these may damage the finish.
- **Protection:** Use chair pads or felt protectors under the legs to avoid scratching or damaging floors. Refrain from placing sharp objects directly on the seat or backrest to prevent scuffs or tears.

Maintenance

- Periodically inspect the chair for loose screws or parts. Tighten them as necessary to maintain stability.
- If any part of the chair shows signs of wear or damage, repair or replace the affected part before continuing use.

Storage

- If you need to store the chair, keep it in a cool, dry location. Avoid placing heavy objects on top of the chair to prevent deformities.

- If storing for an extended period, cover the chair with a protective cloth to prevent dust accumulation.

Safety Warnings

- Do not stand or climb on the chair.
- Avoid using the chair on uneven surfaces or near sharp edges to prevent tipping or accidents.
- Keep the chair away from open flames and heat sources to prevent damage to the materials.