

Simple Green 32 oz. Foaming Coil Cleaner, Trigger Spray

Instructions For Use:

1. Turn off or disconnect power to unit being cleaned and wait until coils are cool before cleaning.
2. Apply cleaner to soiled surfaces and let sit for 2-5 minutes. If heavy foaming is needed, apply liquid by a pressurized or pump-up spray applicator. Avoid spraying onto electrical wires or connections.
3. This product is self-rinsing on condensate-producing coils, simply leave cleaner to dry. Otherwise, damp wipe or rinse clean with water.
4. For extremely stubborn soils, repeat steps 2 and 3 as necessary.
5. Once rinsed or dried, restore power to unit.

*NON-CORROSIVE when used as directed on cool surfaces.