
INSTRUCTIONMANUAL



Pleasekeepthismanualandproductcodenumberforfuturereference andfororderingreplacementpartsifnecessary.

GENERAL INSTRUCTIONS

- Read this manual carefully and completely before proceeding.
- It is recommended that you wear safety glasses at all times during the installation.

INSTALLATION OVER CERAMIC TILES

- If your shower door is to be installed over ceramic tiles, the tiles should lay completely under the wall jamb.
- Silicone should be used to seal the gap where the ceramic tiles meet the fixed panel.


NOTICE


- Caulking : no sealant is required inside the shower, unless otherwise stated.
- Some models are equipped with clear sealing gaskets.

CARE FOR YOUR SHOWER DOOR

- Never use scouring powder pads or sharp instruments on metal pieces or glass panels.
 An occasional wiping down with a mild soap diluted in water is all that is needed to keep the panels andmetal parts looking new
- We recommend wiping the glass panels with a squeegee after each use.

Tools Required





NO.	Name	Picture	Qty
1	8mm Wall plug		4
2	screw ST5x40	0	4
3	Door seal		2
4	Sliding door		2
5	Towel bar		2
6	Anti-splash threshold		1
7	Guide block	ATEN,	1
8	6mm Wall plug		1

NO.	Name	Picture	Qty
9	screw ST4x30		1
10	Wall bracket		2
11	Roller (Ø45 or Ø60)	•	4
12	Anti jumping knob	49)	4
13	Guide Rail		1
14	Rectangle damper		4
15	Door seal		2

