



WG Wood Products

213 Field End Street, Sarasota, FL 34240 • 913-829-6000 • FAX: 941-822-0599

USE AND CARE INSTRUCTIONS

CLEANING:

Use only a damp cloth to clean any painted surface of your cabinet. If you have a stained finish, the same applies – use only a damp cloth. Do NOT use cleaners such as 409, Fantastic, Pine Sol or other harsh chemicals as this may damage your finish. We are not responsible for, nor will we replace products which have been cleaned using any type of harsh chemical to clean it. If you ruin your finish, we are NOT responsible for repairing or replacing it.

HINGES:

Hinges and other hardware should never need to be oiled. Should your hinges ever develop a squeak, placing a small drop of 3in1 oil, or a squirt of WD-40 on the inside of the hinge arm will take care of any issue. Do not get these products on your finish as it could stain or damage the finish. We are NOT responsible for repairing or replacing it.

GLASS SHELVES:

All glass shelves can be cleaned using any glass cleaner or can also be placed in the dishwasher to clean them.