
USE AND CARE GUIDE

ROCK CLIFF 34X34IN STEEL CHAT TABLE



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents2	Pre-Assembly
	Planning Assembly
Save These Instructions	Hardware Included 4
Read All Instructions before Use	Package Contents
Narranty	
What is covered	Care and Cleaning
What is not covered	•

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: THIS TABLE WAS MADE FOR THE EXPLICIT PURPOSE OF PROVIDING OUTDOOR FUNCTIONS AND IS NOT TO BE USED AS A TOY. THIS PRODUCT IS INTENDED FOR NORMAL OUTDOOR USE; HOWEVER, THE MANUFACTURER RECOMMENDS STORING AND/OR COVERING THIS PRODUCT WHEN ANY FORMIDABLE/SEVERE WEATHER IS APPROACHING.



WARNING: DO NOT LOCATE THIS PRODUCT NEAR OPEN FLAMES. DO NOT USE THIS PRODUCT AS A SUPPORT. DO NOT SHAKE, LEAN OR CLIMB ON THE PRODUCT. CHILDREN UNDER THE AGE OF 10, NEAR THE PRODUCT, SHOULD BE SUPERVISED BY A COMPETENT ADULT AT ALL TIMES. THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE AND WILL VOID THE WARRANTY.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Please keep children out of the assembly area before assembly.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat sources.



WARNING: Please keep children out of the assembly area before assembly.



WARNING: This table is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the table.

Warranty

3 YEAR FRAME LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HAMPTONBAY.com.

Pre-assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

Pre-assembly (continued)

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6x15 Combination Bolt	12+1
BB	Hex Wrench	1

PACKAGE CONTENTS



Part	Description	Quantity
Α	Table Top	1
В	Table Leg	4


Assembly

1 Attaching The Table Legs To The Table Top




NOTE: Loosely tighten all bolts using the hex wrench (BB).

- □ Place the table top (A) upside down on a soft surface.
- Attach the table legs (B) to the table top (A) using M6x15 combination bolts (AA).



2 Tightening All The Bolts

- Once all of the bolts are in place, fully tighten all the bolts using the hex wrench (BB).
- Turn the table right side up.
- □ Ensure all connections are secure before use.



Care and Cleaning

- For best results, clean the frame with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- □ Do not clean with abrasive materials, bleach or solvents.
- □ Store the table in a dry sheltered place when not in use.
- Keep the table away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

5

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM


Retain this manual for future use.

For certification use only

Factory Table ID #FTS81230

USE AND CARE GUIDE

ROCK CLIFF STEEL WICKER CORNER CHAIR - BARE



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents2	Pre-Assembly
	Planning Assembly
Save These Instructions	Hardware Included
Read All Instructions before Use	Package Contents
Narranty	
What is covered	Care and Cleaning
What is not covered	

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: THIS CHAIR WAS MADE FOR THE EXPLICIT PURPOSE OF PROVIDING OUTDOOR FUNCTIONS AND IS NOT TO BE USED AS A TOY. THIS PRODUCT IS INTENDED FOR NORMAL OUTDOOR USE; HOWEVER, THE MANUFACTURER RECOMMENDS STORING AND/OR COVERING THIS PRODUCT WHEN ANY FORMIDABLE/SEVERE WEATHER IS APPROACHING.



WARNING: DO NOT LOCATE THIS PRODUCT NEAR OPEN FLAMES. DO NOT USE THIS PRODUCT AS A SUPPORT. DO NOT SHAKE, LEAN OR CLIMB ON THE PRODUCT. CHILDREN UNDER THE AGE OF 10, NEAR THE PRODUCT, SHOULD BE SUPERVISED BY A COMPETENT ADULT AT ALL TIMES. THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE AND WILL VOID THE WARRANTY.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- Do not move the chair while it is occupied. Failure to obey this caution could result in injury.
- 4. Do not rock in the chair as you may fall and cause serious injury.
- 5. Please keep children out of the assembly area before assembly.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat sources.



WARNING: Weight limit for the chair is 250lbs (113.39Kg).



WARNING: This chair unit is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the chair.

Warranty

3 YEAR FRAME LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HAMPTONBAY.com.

Pre-assembly

PLANNING ASSEMBLY

- Read all instructions before assembly.
- □ To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.




NOTE: More than one person may be required to assemble this product.

Pre-assembly (continued)

HARDWARE INCLUDED





NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6x20 Combination Bolt	3+1
BB	M6x45 Combination Bolt	5+1
CC	Hex Wrench	1

PACKAGE CONTENTS





Part	Description	Quantity
Α	Right Backrest	1
В	Left Backrest	1
С	Seat	1
D	Back Cushion 1	1
E	Back Cushion 2	1
F	Seat Cushion	1
G	Metal Clip	2


Assembly

1 Attaching The Seat To The Right Backrest



NOTE: Loosely tighten all bolts using the hex wrench (CC).

- □ Place the right backrest (A) upside down on a soft surface.
- Attach the seat (C) to the right backrest (A) using M6x20 combination bolt (AA) and M6x45 combination bolts (BB).




2 Attaching The Right Backrest And Seat To The Left Backrest



NOTE: Loosely tighten all bolts using the hex wrench (CC).

- □ Place the left backrest (B) upside down on a soft surface.
- Attach the seat (C) to the left backrest (B) using M6x20 combination bolt (AA) and M6x45 combination bolts (BB).
- Attach right backrest (A) to the left backrest (B) using M6x45 combination bolt (BB).




Assembly (continued)

3 Connecting The Right Backrest And The Left Backrest




NOTE: Loosely tighten all bolts using the hex wrench (CC).

□ Turn the chair right side up, connect the right backrest (A) and the left backrest (B) using M6x20 combination bolt (AA).



4 Tightening All The Bolts

- Once all of the bolts are in place, fully tighten all the bolts using hex wrench (CC).
- Place the back cushion 1 (D), back cushion 2 (E), and seat cushion (F) on the chair.
- □ Ensure all connections are secure before use.




Assembly (continued)

5 Set Assembly




NOTE: The left/right arm loveseat are not included, and this step is only considerable when left/right arm loveseat are purchased from HomeDepot.com.

□ Using the metal clips (G) to create beautiful sectional sets, as shown below.



Use the metal clip to connect the sectional



Care and Cleaning

- □ For best results, clean the frame and fabric with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach or solvents.
- □ Store the chair in a dry sheltered place when not in use.
- □ Keep the chair away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM


Retain this manual for future use.

For certification use only

Factory Corner Chair ID # FRS81094B

USE AND CARE GUIDE

ROCK CLIFF STEEL WICKER LEFT/RIGHT ARM LOVESEAT - BARE



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents2	Planning Assembly
Important Safety Instructions2	Hardware Included
Save These Instructions	
Read All Instructions before Use	Right Arm Loveseat Package Contents 5
Warranty	Left Arm Loveseat Assembly
What is covered	Right Arm Loveseat Assembly8
What is not covered	Care and Cleaning
Pre-Assembly3	

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: THIS LOVESEAT WAS MADE FOR THE EXPLICIT PURPOSE OF PROVIDING OUTDOOR FUNCTIONS AND IS NOT TO BE USED AS A TOY. THIS PRODUCT IS INTENDED FOR NORMAL OUTDOOR USE; HOWEVER, THE MANUFACTURER RECOMMENDS STORING AND/OR COVERING THIS PRODUCT WHEN ANY FORMIDABLE/SEVERE WEATHER IS APPROACHING.



WARNING: DO NOT LOCATE THIS PRODUCT NEAR OPEN FLAMES. DO NOT USE THIS PRODUCT AS A SUPPORT. DO NOT SHAKE, LEAN OR CLIMB ON THE PRODUCT. CHILDREN UNDER THE AGE OF 10, NEAR THE PRODUCT, SHOULD BE SUPERVISED BY A COMPETENT ADULT AT ALL TIMES. THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE AND WILL VOID THE WARRANTY.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- Do not move the loveseat while it is occupied. Failure to obey this caution could result in injury.
- 4. Do not rock in the loveseat as you may fall and cause serious injury.
- 5. Please keep children out of the assembly area before assembly.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat sources.



WARNING: Weight limit for the loveseat is 250lbs (113.39Kg) for each seat.



WARNING: This loveseat unit is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the loveseat.

Warranty

3 YEAR FRAME LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HAMPTONBAY.com.

Pre-assembly

PLANNING ASSEMBLY

- Read all instructions before assembly.
- □ To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.




NOTE: More than one person may be required to assemble this product.

Pre-assembly (continued)

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6x20 Combination Bolt	10+1
BB	M6x45 Combination Bolt	6+1
CC	Hex Wrench	1


LEFT LOVESEAT PACKAGE CONTENTS



Part	Description	Quantity
Α	Left Arm	1
В	Left Arm Loveseat Back	1
С	Left Arm Loveseat Seat	1
D	Seat Cushion	2
E	Back Cushion	2
F	Metal Clip	1

Pre-assembly (continued)

RIGHT LOVESEAT PACKAGE CONTENTS



Part	Description	Quantity
G	Right Arm	1
Н	Right Arm Loveseat Back	1
I	Right Arm Loveseat Seat	1
D	Seat Cushion	2
Е	Back Cushion	2
F	Metal Clip	1


Assembly - Left Arm Loveseat Chair

Attaching The Left Arm Loveseat Seat To The Left Arm Loveseat Back



NOTE: Loosely tighten all bolts using the hex wrench (CC).

- □ Place the left arm loveseat back (B) upside down on a soft surface.
- Attach the left arm loveseat seat (C) to the left arm loveseat back (B) using M6x20 combination bolt (AA) and M6x45 combination bolts (BB).




2 Attach The Left Arm Loveseat Back And Left Arm Loveseat Seat To The Left Arm



NOTE: Loosely tighten all bolts using the hex wrench (CC).

- □ Place the left arm (A) upside down on a soft surface.
- Attached the left arm loveseat back (B) and the left arm loveseat seat (C) to the left arm (A) using M6x20 combination bolts (AA).




Assembly - Left Arm Loveseat Chair (continued)

3 Connecting The Left Arm Loveseat Back And Left Arm




NOTE: Loosely tighten all bolts using the hex wrench (CC).

□ Turn the loveseat right side up, connect the left arm loveseat back (B) and left arm (A) using M6x20 combination bolt (AA).



4 Tightening All The Bolts

- Once all of the bolts are in place, fully tighten all the bolts using hex wrench (CC).
- □ Place the seat cushions (D) and back cushions (E) on the loveseat.
- □ Ensure all connections are secure before use.




Assembly - Right Arm Loveseat Chair

Attaching The Right Arm Loveseat Seat To The Right Arm Loveseat Back



NOTE: Loosely tighten all bolts using the hex wrench (CC).

- □ Place the right arm loveseat back (H) upside down on a soft surface.
- □ Attach the right arm loveseat seat (I) to the right arm loveseat back (H) using M6x20 combination bolt (AA) and M6x45 combination bolts (BB).




2 Attach The Right Arm Loveseat Back And Right Arm Loveseat Seat To The Right Arm



NOTE: Loosely tighten all bolts using the hex wrench (CC).

- □ Place the right arm (G) upside down on a soft surface.
- □ Attached the right arm loveseat back (H) and the right arm loveseat seat (I) to the right arm (G) using M6x20 combination bolts (AA).




Assembly - Right Arm Loveseat Chair (continued)

3 Connecting The Right Arm Loveseat Back And Right Arm




NOTE: Loosely tighten all bolts using the hex wrench (CC).

Turn the loveseat right side up, connect the right arm loveseat back
 (H) and right arm (G) using M6x20 combination bolt (AA).



4 Tightening All The Bolts

- Once all of the bolts are in place, fully tighten all the bolts using hex wrench (CC).
- □ Place the seat cushions (D) and back cushions (E) on the loveseat.
- Ensure all connections are secure before use.




Assembly (continued)

5 Set Assembly




NOTE: The corner chair is not included, and this step is only considerable when corner chair is purchased from HomeDepot.com.

□ Using the metal clips (F) to create beautiful sectional sets, as shown below.



Use the metal clip to connect the sectional



Care and Cleaning

- □ For best results, clean the frame and fabric with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- □ Do not clean with abrasive materials, bleach or solvents.
- □ Store the loveseat in a dry sheltered place when not in use.
- □ Keep the loveseat away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.

For certification use only

Factory Left Arm Loveseat ID # FRS81094L Factory Right Arm Loveseat ID # FRS81094AL