



40V BATTERIES

Due to the size of these **40V** batteries



2Ah
OP40204, OP4020A



4Ah
OP40404, OP4040A1



6Ah
OP40605, OP4060A1



8Ah
OP40804, OP4080A



12Ah
OP40125, OP4012A1



EDGE 4Ah
OP40406T, OP40406TA



EDGE 8Ah
OP40806T, OP40806TA

These batteries will **not** work with the previous **40V** models shown below



40V SNOW BLOWER
RY40805, RY40850



40V CHAINSAWS
RY40502, RY40500, RY40511



40V PRESSURE
WASHER
RY40PW01BT



40V MOWERS
RY40108, RY40109, RY40100, RY40101, RY40104, RY40106, RY40107, RY40180, RY40190

The 40V 2Ah Battery and 40V EDGE 4Ah Battery will fit with the chainsaws listed above.