

Item #1005614292

1012048417


1012094943

Model #755.0312.000

HAMPTON BAY®

USE AND CARE GUIDE

LAUREL OAKS STATIONARY DINING CHAIR



Scan for easy 3D instructions

Tap. Zoom. Rotate with official interactive instructions on the BILT app.



BILT®



THANK YOU

We appreciated the trust and confidence you have placed in Hampton Bay through the purchase of this chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents	2	Hardware Included.	3
Safety Information	2	Package Contents	4
Warranty	2	Assembly.	5-6
What is covered	2	Care and Cleaning	7
What is not covered	2		
Pre-Assembly	3		
Planning Assembly.	3		

Safety Information

SAVE THESE INSTRUCTIONS

To reduce the risk of injury:

1. Close supervision is required when this table is used by or near children or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



CAUTION: Read all of the instructions in this manual before you begin assembly. Failure to do so may result in faulty assembly and potential injury!

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

We warrant the product to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, freezing, or abusive use. In addition, purchased parts are not covered under this warranty.

We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact Customer Care at 1-800-841-1350 or visit www.hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.




NOTE: More than one person may be required to assemble this product.


HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.




Part	Description	Quantity
AA	M6 x 20 bolt	4
BB	Bolt cap	10
CC	Allen driver	1
YY	Hex. screw (6 mm)	1
ZZ	Ratchet wrench	1



Please use wrench (ZZ) + hex. screw (YY).



Tighten the screws




Loosen the screws

Pre-Assembly

PACKAGE CONTENTS



NOTE: Do not fully tighten bolts/screws until all pieces are loosely assembled.




Part	Description	Quantity
A	Chair back	1
B	Chair seat	1
C	Left arm sitting	1
D	Right arm sitting	1
E	Seat cushion	1
F	Back cushion	1

Assembly

1 Unfolding the chair seat and chair back

- Unfold the chair back (A) and the chair seat (B) to open.




2 Attaching the right arm sitting to the chair seat

- Attach the right arm sitting (D) to the chair seat (B) using M6 bolt (AA). Then tighten the pre-set bolt.



NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (CC) or ratchet wrench (ZZ) and hex. screw (YY) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Adding corresponding bolt caps (BB) after final assembly finished.




3 Attaching the right arm sitting to the chair back

- Attach the right arm sitting (D) to the chair back (A) using M6 bolt (AA).



NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (CC) or ratchet wrench (ZZ) and hex. screw (YY) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Adding corresponding bolt caps (BB) after final assembly finished.




4 Attaching the left arm sitting to the chair seat

- Attach the left arm sitting (D) to the chair seat (B) using M6 bolt (AA). Then tighten the pre-set bolt.



NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (CC) or ratchet wrench (ZZ) and hex. screw (YY) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Adding corresponding bolt caps (BB) after final assembly finished.




Assembly

5 Attaching the left arm sitting to the chair back

- Attach the left arm sitting (C) to the chair back (A) using M6 bolts.




NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (CC) or ratchet wrench (ZZ) and hex. screw (YY) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Adding corresponding bolt caps (BB) after final assembly finished.




6 Adding the bolt caps to the pre-set bolts

- Add the bolt caps (BB) to the pre-set bolts.



7 Adding the cushions

- Add seat cushion (E) and back cushion (F) to secure to chair.



Care and Cleaning

- Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- Rinse with clean water and dry with a soft, absorbent cloth towel.
- Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.
- Furniture covers are a great way to protect your investment from harsh elements of weather and UV light. However, it is important to ensure the furniture and covers are free of moisture and debris before covering. It is also necessary to promptly uncover furniture after precipitation and during periods of high humidity to prevent moisture build up. Failure to do so can lead to permanent surface and finish damage, which is not covered under warranty.

HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM


Retain this manual for future use.

Item #1005614292
1012048417
1012094943
Model #755.0313.000

HAMPTON BAY®

USE AND CARE GUIDE

LAUREL OAKS MOTION DINING CHAIR



Scan for easy 3D instructions

Tap. Zoom. Rotate with official interactive instructions on the BILT app.



BILT®



THANK YOU

We appreciated the trust and confidence you have placed in Hampton Bay through the purchase of this chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents	2	Hardware Included.	3
Safety Information	2	Package Contents	4
Warranty	2	Assembly.	5-6
What is covered	2	Care and Cleaning	7
What is not covered	2		
Pre-Assembly	3		
Planning Assembly	3		

Safety Information

SAVE THESE INSTRUCTIONS

To reduce the risk of injury:

1. Close supervision is required when this table is used by or near children or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



CAUTION: Read all of the instructions in this manual before you begin assembly. Failure to do so may result in faulty assembly and potential injury!

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

We warrant the product to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, freezing, or abusive use. In addition, purchased parts are not covered under this warranty.

We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact Customer Care at 1-800-841-1350 or visit www.hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.




NOTE: More than one person may be required to assemble this product.


HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.




Part	Description	Quantity
AA	M6 x 20 bolt	4
BB	Bolt cap	10
CC	Allen driver	1
YY	Hex. screw (6 mm)	1
ZZ	Ratchet wrench	1



Please use wrench (ZZ) + hex. screw (YY).



Tighten the screws




Loosen the screws

Pre-Assembly

PACKAGE CONTENTS



NOTE: Do not fully tighten bolts/screws until all pieces are loosely assembled.




Part	Description	Quantity
A	Chair back	1
B	Chair seat	1
C	Left arm sitting	1
D	Right arm sitting	1
E	Seat cushion	1
F	Back cushion	1
G	Swivel chair base	1
H	Swivel collar	1

Assembly

1 Unfolding the folded chair back and chair seat

- Unfold the chair back (A) and the chair seat (B) to open.




2 Attaching the right arm sitting to the chair seat

- Attach the right arm sitting (D) to the chair seat (B) using M6 bolt (AA). Then tighten the pre-set bolt.



NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (CC) or ratchet wrench (ZZ) and hex. screw (YY) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Adding corresponding bolt caps (BB) after final assembly finished.




3 Attaching the right arm sitting to the chair back

- Attach the right arm sitting (D) to the chair back (A) using M6 bolt (AA).



NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (CC) or ratchet wrench (ZZ) and hex. screw (YY) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Adding corresponding bolt caps (BB) after final assembly finished.




4 Attaching the left arm sitting to the chair seat

- Attach the left arm sitting (C) to the chair seat (B) using M6 bolt (AA). Then tighten the pre-set bolt.



NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (CC) or ratchet wrench (ZZ) and hex. screw (YY) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Adding corresponding bolt caps (BB) after final assembly finished.




Assembly

5 Attaching the left arm sitting to the chair back

- Attach the left arm sitting (C) to the chair back (A) using M6 bolts.




NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (CC) or ratchet wrench (ZZ) and hex. screw (YY) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Adding corresponding bolt caps (BB) after final assembly finished.




6 Attaching the chair seat to the chair base

- First put the swivel collar (H) over chair base (G). Then insert the chair seat (B) into the chair base (G) and press down to secure.




7 Adding the bolt caps to the pre-assembled bolts

- Add the bolt caps (BB) to the pre-set bolts.



8 Adding the cushions

- Add seat cushion (E) and back cushion (F) to secure to chair.



Care and Cleaning

- Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- Rinse with clean water and dry with a soft, absorbent cloth towel.
- Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.
- Furniture covers are a great way to protect your investment from harsh elements of weather and UV light. However, it is important to ensure the furniture and covers are free of moisture and debris before covering. It is also necessary to promptly uncover furniture after precipitation and during periods of high humidity to prevent moisture build up. Failure to do so can lead to permanent surface and finish damage, which is not covered under warranty.

HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM


Retain this manual for future use.

Item #1005614292
1012095599
1012095657
Model #745.0301.000

HAMPTON BAY®

USE AND CARE GUIDE

LAUREL OAKS DINING TABLE



Scan for easy 3D instructions

Tap. Zoom. Rotate with official interactive instructions on the BILT app.



BILT®

Download on the
App Store

GET IT ON
Google Play



THANK YOU

We appreciated the trust and confidence you have placed in Hampton Bay through the purchase of this table. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents	2	Hardware included.	3
Safety Information	2	Package Contents	4
Warranty	2	Assembly.	5
What is covered	2	Care and Cleaning	6
What is not covered	2		
Pre-Assembly	3		
Planning Assembly	3		

Safety Information

SAVE THESE INSTRUCTIONS

To reduce the risk of injury:

1. Close supervision is required when this table is used by or near children or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



CAUTION: Read all of the instructions in this manual before you begin assembly. Failure to do so may result in faulty assembly and potential injury!



The table is not intended to be supported with only an umbrella insert. The umbrella insert should always be used with a suitable base.

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

We warrant the product to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, freezing, or abusive use. In addition, purchased parts are not covered under this warranty.

We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact Customer Care at 1-800-841-1350 or visit www.hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.




NOTE: More than one person may be required to assemble this product.


HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.




Part	Description	Quantity
AA	M8 x 40 bolt	2
BB	Allen driver	1
XX	Hex. screw (8 mm)	1
ZZ	Ratchet wrench	1



Please use wrench (ZZ) + hex. screw (XX).



Tighten the screws




Loosen the screws

Pre-Assembly

PACKAGE CONTENTS



NOTE: Do not fully tighten bolts/screws until all pieces are loosely assembled.




Part	Description	Quantity
A	Table top	1
B	Table legs	4
C	Umbrella insert	1

Assembly

1 Unfolding the table top


- Unfold the table top (A), so the top surface is facing down.



Pinch Point Hazard.
Keep hands clear of this area.


2 Inserting and tightening the locking bolts

- Insert and tighten the M8 bolts (AA) using either the Allen driver (BB) or the Ratchet wrench (ZZ) and hex screw (XX) to secure the table top in the open position.




3 Attaching table legs to table top

- Screw the table legs (B) into the table top.



4 Adding the umbrella insert

- Turn the table onto its legs, and add the umbrella insert (C). The table is now ready to use.



Care and Cleaning

- Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- Rinse with clean water and dry with a soft, absorbent cloth towel.
- Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.
- Furniture covers are a great way to protect your investment from harsh elements of weather and UV light. However, it is important to ensure the furniture and covers are free of moisture and debris before covering. It is also necessary to promptly uncover furniture after precipitation and during periods of high humidity to prevent moisture build up. Failure to do so can lead to permanent surface and finish damage, which is not covered under warranty.

HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM

Retain this manual for future use.