

# PRORUN®


**//////** *POWER and RELIABILITY™*

**GAS///**

**CHAINSAW**

**MODEL: PCS560C**

## PARTS LIST



Everything PRORUN

Please let us know what you think.  
To leave a review and see our full line of products, visit:

**proruntech.com** ★ ★ ★ ★ ★

1-844-905-0882, [info@proruntech.com](mailto:info@proruntech.com)


Version: B - Issue Date: 2023/05/04

**SPARE PARTS / ENGINE**

**CLUTCH ASSEMBLY**

Part Number: 68856001


| No. | Description                                          | Qty |
|-----|------------------------------------------------------|-----|
| 70  | Clutch Gasket                                        | 1   |
| 79  | Clutch Shoe                                          | 3   |
| 80  | Clutch Retaining Frame                               | 1   |
| 81  | Clutch Spring                                        | 3   |
| 82  | Plain Washer $\Phi 17.8 \times \Phi 10.1 \times 0.8$ | 1   |
| 83  | Needle Bearing 10×14×13                              | 1   |



**REDUCING VALVE**

Part Number: 20070024

| No. | Description    | Qty |
|-----|----------------|-----|
| 44  | Reducing Valve | 1   |




**SPARE PARTS / CHASSIS AND ENCLOSURE**

**TOP COVER ASSEMBLY**

Part Number: 20077316


| No. | Description                      | Qty |
|-----|----------------------------------|-----|
| 17  | Cover                            | 1   |
| 19  | Cover Liner                      | 3   |
| 20  | Cover Screw Assembly             | 3   |
| 21  | Reducing Valve Protective Shield | 1   |
| 22  | Anti-Vibration Cap               | 1   |
| 23  | Idling Speed Adjust Guide Sleeve | 1   |
| 24  | Cover Heat Insulation Film       | 1   |



**SPARE PARTS / CHASSIS AND ENCLOSURE****CHAIN COVER ASSEMBLY**


Part Number: 20085775

| No. | Description      | Qty |
|-----|------------------|-----|
| 36  | Right Side Cover | 1   |
| 37  | Nut              | 2   |

**FUEL CAP ASSEMBLY**


Part Number: 20073419

| No. | Description       | Qty |
|-----|-------------------|-----|
| 69  | Fuel Throttle Cap | 1   |
| 70  | O-Ring 24.7x3.55  | 1   |
| 71  | Anti-Drop Plate   | 1   |

**OIL FILLER CAP ASSEMBLY**


Part Number: 20074530

| No. | Description            | Qty |
|-----|------------------------|-----|
| 12  | Oil Port Cap           | 1   |
| 13  | Washer 22.4x3.55       | 1   |
| 14  | Fuel Port Cap Retainer | 1   |

**SPARE PARTS / STARTING MECHANISM****SPARK PLUG**

Part Number: 20079314


| No. | Description | Qty |
|-----|-------------|-----|
| 40  | Spark Plug  | 1   |



**SPARE PARTS / STARTING MECHANISM****STARTER ASSEMBLY**


Part Number: 20085773

| No. | Description                       | Qty |
|-----|-----------------------------------|-----|
| 3   | Starter Handle                    | 1   |
| 4   | Pull Cord Sheath                  | 1   |
| 5   | Starter Pull Cord                 | 1   |
| 6   | Starter Cover                     | 1   |
| 7   | Bossing                           | 1   |
| 8   | Self-Tapping Screw ST4.2x14       | 2   |
| 9   | Easily Actuated Coil Spring       | 1   |
| 10  | Easily Actuated Coil Spring Cover | 1   |
| 11  | Starter Plate                     | 1   |
| 12  | Easy Start-Coil Spring            | 1   |
| 13  | Easy Start-Coil Spring Cover      | 1   |
| 14  | Washer 5.2x15x1.5                 | 1   |
| 15  | Self-Tapping Screw ST4.8x14       | 1   |

**STARTER GRIP AND ROPE ASSEMBLY**


Part Number: 68856002

| No. | Description       | Qty |
|-----|-------------------|-----|
| 3   | Starter Handle    | 1   |
| 5   | Starter Pull Cord | 1   |

**START ROPE COVER ASSEMBLY**

Part Number: 68856003


| No. | Description   | Qty |
|-----|---------------|-----|
| 6   | Starter Cover | 1   |
| 7   | Bossing       | 1   |



**SPARE PARTS / STARTING MECHANISM****IGNITION ASSEMBLY**


Part Number: 68856008

| No. | Description        | Qty |
|-----|--------------------|-----|
| 7   | Igniter            | 1   |
| 8   | Engine Stop Switch | 1   |

**POWER SWITCH ASSEMBLY**


Part Number: 20050823

| No. | Description        | Qty |
|-----|--------------------|-----|
| 8   | Engine Stop Switch | 1   |
| 9   | Flameout Line      | 1   |
| 10  | Ground Wire        | 1   |

**SPARE PARTS / CARBURETOR****CARBURETOR ASSEMBLY**

Part Number: 68856004

| No. | Description              | Qty |
|-----|--------------------------|-----|
| 113 | Carburetor               | 1   |
| 114 | Throttle Base            | 1   |
| 115 | Throttle Rod             | 1   |
| 111 | Carburetor Sealing Plate | 1   |






**SPARE PARTS / BAR AND CHAIN**

**20-INCH GUIDE BAR**

Part Number: 30016600


| No. | Description       | Qty |
|-----|-------------------|-----|
| 77  | Guide Bar 20 Inch | 1   |



**20-INCH SAW CHAIN**

Part Number: 30019451


| No. | Description       | Qty |
|-----|-------------------|-----|
| 76  | Saw Chain 20 Inch | 1   |



**20-INCH BAR AND CHAIN COVER**

Part Number: 30001190

| No. | Description             | Qty |
|-----|-------------------------|-----|
| 75  | Guide Bar Cover 20 Inch | 1   |




**SPARE PARTS / FILTER AND ACCESSORIES**

**AIR FILTER**

Part Number: 20057657

| No. | Description | Qty |
|-----|-------------|-----|
| 121 | Air Filter  | 1   |



**SPARE PARTS / FILTER AND ACCESSORIES****AIR FILTER KNOB ASSEMBLY**

Part Number: 68856005

| No. | Description        | Qty |
|-----|--------------------|-----|
| 122 | Rotary Knob Washer | 1   |
| 123 | Rotary Knob        | 1   |

**123****122****OIL FILTER ASSEMBLY**


Part Number: 68856006

| No. | Description       | Qty |
|-----|-------------------|-----|
| 57  | Oil Pipe          | 1   |
| 58  | Oil Filter        | 1   |
| 59  | Oil Filter Screen | 1   |


**57****58****59****BUMPER SPIKE ASSEMBLY**

Part Number: 68856007

| No. | Description   | Qty |
|-----|---------------|-----|
| 60  | Bumper Spikes | 1   |
| 61  | Screw M5x16   | 2   |



**ASSEMBLY PARTS LIST**



**ASSEMBLY PARTS LIST**

| No. | Description                       | Qty |
|-----|-----------------------------------|-----|
| 1   | Screw M5x16                       | 3   |
| 2   | Starter Unit                      | 1   |
| 3   | Starter Handle                    | 1   |
| 4   | Pull Cord Sheath                  | 1   |
| 5   | Starter Pull Cord                 | 1   |
| 6   | Starter Cover                     | 1   |
| 7   | Bossing                           | 1   |
| 8   | Self-Tapping Screw ST4.2x14       | 2   |
| 9   | Easily Actuated Coil Spring       | 1   |
| 10  | Easily Actuated Coil Spring Cover | 1   |
| 11  | Starter Plate                     | 1   |
| 12  | Easy Start-Coil Spring            | 1   |
| 13  | Easy Start-Coil Spring Cover      | 1   |
| 14  | Washer 5.2x15x1.5                 | 1   |
| 15  | Self-Tapping Screw ST4.8x14       | 1   |
| 16  | Cover Unit                        | 1   |
| 17  | Cover                             | 1   |
| 18  | Marking Plate                     | 1   |
| 19  | Cover Liner                       | 3   |
| 20  | Cover Screw Assembly              | 3   |
| 21  | Reducing Valve Protective Shield  | 1   |
| 22  | Anti-Vibration Cap                | 1   |
| 23  | Idling Speed Adjust Guide Sleeve  | 1   |
| 24  | Cover Heat Insulation Film        | 1   |
| 25  | Screw M5x20                       | 1   |
| 26  | Handle Unit                       | 1   |
| 27  | Anti-Vibration Base 3             | 1   |
| 28  | Anti-Vibration Rope 3             | 1   |
| 29  | Anti-Vibration Spring 3           | 1   |
| 30  | Teeth Shape Sponge                | 1   |
| 31  | Handle                            | 1   |
| 32  | Anti-Vibration Spring 1           | 1   |
| 33  | Anti-Vibration Base 1             | 1   |
| 34  | Self-Tapping Screw ST6.3x32       | 4   |
| 35  | Right Side Cover Assembly         | 1   |
| 36  | Right Side Cover                  | 1   |
| 37  | Nut                               | 2   |
| 38  | Anti-Vibration 2 Assembly         | 1   |
| 39  | Screw M4x14                       | 1   |


| No. | Description                     | Qty |
|-----|---------------------------------|-----|
| 40  | Upper Anti-Vibration Base 2     | 1   |
| 41  | Anti-Vibration Spring 2         | 1   |
| 42  | Anti-Vibration Rope 2           | 1   |
| 43  | Rope Sponge                     | 1   |
| 44  | Lower Anti-Vibration Base 2     | 1   |
| 45  | Self-Tapping Screw ST4.8x16     | 1   |
| 46  | Base Cover Plate                | 1   |
| 47  | Oil Pump Pipe Protective Sleeve | 1   |
| 48  | Balancer Seat                   | 1   |
| 49  | Balancer Body Unit              | 1   |
| 50  | Trigger Control Rack            | 1   |
| 51  | Self-Tapping Screw ST4.2x22     | 1   |
| 52  | Hander Cover                    | 1   |
| 53  | Limited Block                   | 1   |
| 54  | Cylinder Pin $\Phi 3 \times 25$ | 1   |
| 55  | Cable Accelerator               | 1   |
| 56  | Oil Pump Pipe                   | 1   |
| 57  | Long Oil Nozzle                 | 1   |
| 58  | Limited Block                   | 1   |
| 59  | Trigger Spring                  | 1   |
| 60  | Trigger                         | 1   |
| 61  | Guide Pipe                      | 1   |
| 62  | Oil Bubble                      | 1   |
| 63  | Upper Fuel Pipe                 | 1   |
| 64  | Fuel Throttle                   | 1   |
| 65  | Lower Fuel Pipe                 | 1   |
| 66  | Spring                          | 1   |
| 67  | Fuel Filter Unit                | 1   |
| 68  | Fuel Throttle Cap Assembly      | 1   |
| 69  | Fuel Throttle Cap               | 1   |
| 70  | O-Ring 24.7x3.55                | 1   |
| 71  | Anti-Drop Plate                 | 1   |
| 72  | Base                            | 1   |
| 73  | Support Screw M5x16             | 1   |
| 74  | Bar And Chain Assembly          | 1   |
| 75  | Guide Bar Cover 20 Inch         | 1   |
| 76  | Saw Chain 20 Inch               | 1   |
| 77  | Guide Bar 20 Inch               | 1   |



**POWER and RELIABILITY™**

**MODEL: PCS560C**

## ASSEMBLY PARTS LIST



**ASSEMBLY PARTS LIST**

| No. | Description                                         | Qty |
|-----|-----------------------------------------------------|-----|
| 1   | Bolt M8x1                                           | 1   |
| 2   | Rotator Unit                                        | 1   |
| 3   | Key 3x3.5x10                                        | 1   |
| 4   | Screw M5x14                                         | 2   |
| 5   | Blast Pipe                                          | 1   |
| 6   | Screw M5x22                                         | 12  |
| 7   | Igniter                                             | 1   |
| 8   | Engine Stop Switch                                  | 1   |
| 9   | Flameout Line                                       | 1   |
| 10  | Ground Wire                                         | 1   |
| 11  | Oil Port Cap Element                                | 1   |
| 12  | Oil Port Cap                                        | 1   |
| 13  | Washer 22.4x3.55                                    | 1   |
| 14  | Fuel Port Cap Retainer                              | 1   |
| 15  | Wire Protective Cover                               | 1   |
| 16  | Seal 15x22x5                                        | 1   |
| 17  | Throttle Cable Protective Cover                     | 1   |
| 18  | Crankcase LH                                        | 1   |
| 19  | Anti-Vibration Washer                               | 1   |
| 20  | Bearing 6202                                        | 1   |
| 21  | Cylinder Pin $\Phi 4 \times 10$                     | 2   |
| 22  | Seal Washer                                         | 1   |
| 23  | Crankshaft                                          | 1   |
| 24  | Bearing                                             | 1   |
| 25  | Crankcase RH Seal 20x30x5                           | 1   |
| 26  | Piston Pin Spring                                   | 2   |
| 27  | Piston Pin                                          | 1   |
| 28  | Retaining Ring                                      | 2   |
| 29  | Needle Bearing $\Phi 13 \times \Phi 10 \times 12.5$ | 1   |
| 30  | Piston                                              | 1   |
| 31  | Piston Ring                                         | 2   |
| 32  | Cylinder Gasket                                     | 1   |
| 33  | Locating Sleeve                                     | 2   |
| 34  | Upper Damper                                        | 1   |
| 35  | Winter / Summer Conversion Board                    | 1   |
| 36  | Clapboard                                           | 1   |

| No. | Description                 | Qty |
|-----|-----------------------------|-----|
| 37  | Screw M4x14                 | 4   |
| 38  | Screw M4x12                 | 6   |
| 39  | Left Scavenging Cover       | 1   |
| 40  | Spark Plug                  | 1   |
| 41  | Right Scavenging Cover      | 1   |
| 42  | Seal                        | 2   |
| 43  | Cylinder                    | 1   |
| 44  | Reducing Valve              | 1   |
| 45  | Muffler Sealing Plate       | 1   |
| 46  | Muffler Sealing Plate       | 1   |
| 47  | Screw M5x20                 | 2   |
| 48  | Pipe Plug                   | 2   |
| 49  | Muffler Cover               | 1   |
| 50  | Screw M5x16                 | 2   |
| 51  | Screw M5x10                 | 1   |
| 52  | Right Case Body             | 1   |
| 53  | Anti-Vibration Sponge       | 1   |
| 54  | Oil Seal                    | 1   |
| 55  | Oil Tank Vent               | 1   |
| 56  | Bolt M8x30-8.8              | 2   |
| 57  | Oil Pipe                    | 1   |
| 58  | Oil Filter                  | 1   |
| 59  | Oil Filter Screen           | 1   |
| 60  | Bumper Spikes               | 1   |
| 61  | Screw M5x16                 | 2   |
| 62  | Support Sleeve              | 1   |
| 63  | Oil Pump                    | 1   |
| 64  | Screw M4x12                 | 2   |
| 65  | Turbine Unit                | 1   |
| 66  | Turbine                     | 1   |
| 67  | Turbine Lifting Lever       | 1   |
| 68  | Chain Catcher               | 1   |
| 69  | Self-Tapping Screw ST6.3x30 | 1   |
| 70  | Clutch Gasket               | 1   |
| 71  | Reset Device                | 1   |
| 72  | Reset Spring                | 1   |

**ASSEMBLY PARTS LIST**

| No. | Description                                          | Qty |
|-----|------------------------------------------------------|-----|
| 73  | Reset Spring Base                                    | 1   |
| 74  | Front Damper Assembly                                | 1   |
| 75  | Front Damper                                         | 1   |
| 76  | Brake Strap Locating Pin $\Phi 3 \times 8$           | 3   |
| 77  | Front Damper Heat Insulation Film                    | 1   |
| 78  | Clutch Assembly                                      | 1   |
| 79  | Clutch Shoe                                          | 3   |
| 80  | Clutch Retaining Frame                               | 1   |
| 81  | Clutch Spring                                        | 3   |
| 82  | Plain Washer $\Phi 17.8 \times \Phi 10.1 \times 0.8$ | 1   |
| 83  | Needle Bearing $10 \times 14 \times 13$              | 1   |
| 84  | Brake Strap                                          | 1   |
| 85  | Brake Spring Locating Pin $\Phi 3 \times 8$          | 1   |
| 86  | Front Damper Locating Pin                            | 1   |
| 87  | Hinge Bar Locating Pin                               | 1   |
| 88  | Hinge Bar                                            | 1   |
| 89  | E Spring $\Phi 5$                                    | 2   |
| 90  | Brake Spring                                         | 1   |
| 91  | Brake Cover                                          | 1   |
| 92  | Gear Seal $6 \times 2$                               | 1   |
| 93  | Tensioner Gear                                       | 1   |
| 94  | Plastic Briquette Block                              | 1   |
| 95  | Screw M5x10                                          | 1   |
| 96  | Clutch Shell                                         | 1   |
| 97  | Chain Wheel                                          | 1   |
| 98  | Small Anti-Abrasion Plate                            | 1   |
| 99  | E Spring $\Phi 8$                                    | 1   |

| No. | Description                 | Qty |
|-----|-----------------------------|-----|
| 100 | Tension Block               | 1   |
| 101 | Tightener Screw             | 1   |
| 102 | Limited Block               | 1   |
| 103 | Guide Pad                   | 1   |
| 104 | Liner                       | 1   |
| 105 | Air Intake Pipe             | 1   |
| 106 | Screw M4x14                 | 3   |
| 107 | Carburetor Base             | 1   |
| 108 | Support Pad                 | 1   |
| 109 | Retaining Ring              | 1   |
| 110 | Plastic Line                | 1   |
| 111 | Carburetor Sealing Plate    | 1   |
| 112 | Plastic Line                | 1   |
| 113 | Carburetor                  | 1   |
| 114 | Throttle Base               | 1   |
| 115 | Throttle Rod                | 1   |
| 116 | Limited Block               | 1   |
| 117 | Air Intake Base             | 1   |
| 118 | Buffer                      | 2   |
| 119 | Air Filter Holder           | 1   |
| 120 | Nut M5                      | 2   |
| 121 | Air Filter                  | 1   |
| 122 | Rotary Knob Washer          | 1   |
| 123 | Rotary Knob                 | 1   |
| 124 | Case Heat Insulation Film   | 1   |
| 125 | Self-Tapping Screw ST4.2x14 | 2   |

PRORUN regularly improves our products, and you may find slight differences between your machine and descriptions contained within this parts list. Modifications can be made to the machine without notice and without the obligation to update the operator's manuals, provided that the essential safety and functional characteristic remain unaltered. Contact PRORUN Customer Service with any questions and current specifications.