


NO.	PART NAME
1	Handle
2	Screw
3	Handle button
4	Adapter
5	Handle flange
6	O-ring
7	Cartridge(hot water)
8	Inlet pipe
9	Gasket assembly
10	Lock nut
11	Screw
12	Spout
13	O-ring
14	Gasket assembly
15	Lock nut
16	Washer
17	Connector
18	Aerator
19	Cartridge(cold water)
20	Aerator wrench
21	Allen key
22	Flexible hose
23	Plug




WIDE SPREAD LAVATORY FAUCET



ASME A112.18.1/CSA B125.1

RECOMMENDED TOOLS



Attention:
for easy installation, you will need:

1. To read all the installation instruction completely before beginning.
2. To read all the warning, attention and maintenance information.
3. To purchase the proper supply lines.

The tools might be applied to the following places:

