



Use & Care Manual

- Inspect upon receipt and before each use. Never climb a damaged, bent or broken stool.
- Place on a firm level, non-slippery surface.
- When using stool, keep two feet centered on Stool.
- Do not over-reach.
- Store stool in a safe and dry place.
- Keep stool clean