



Troubleshooting Tips for Intellibulb Motion Activated Bulbs

I have the motion bulb what are the settings?

- The Sun/Moon is to keep the motion sensor active throughout day and night time.
- The Moon is to keep the motion sensor active throughout dusk to dawn or a dark/dim lit area.

I turned the bulb on from the switch and it lights up.

- The bulb will light up for the first switch on.
- If you have the bulb in the moon setting in a well-lighted area it should turn off after ten minutes.

How long do the bulbs stay on?

- The bulbs are set to stay on at 10 minutes.

No matter what setting I have it on. The light doesn't go off.

- If you have the bulb inside a closet or pantry on either setting (Sun/Moon-Moon) the sensor will stay active. Due to the location and not enough sunlight hitting the bulb to deactivate the sensor in the bulb. This item can see through solid objects.

My light is outside and doesn't turn off at night?

- This bulb functions off of microwaves. This type of technology can go through objects like wood, cloth, windows, and screens.
- The bulb does have a 15-19ft detection radius.
- Make sure that if you do have more than 1 bulb next to each other to separate them. A recommend distance between bulbs is 16-20ft.
- These bulbs can be triggered by the movement of trees, hedges moving or small outdoor plants moving from the wind.

How can I test this bulb to see if the sensors are working?

- To test the Dust to Dusk sensor
 - The best way to test the bulb is to place it in a fixture that is in a well-lit area (Like outside). Place the bulb on the moon setting. After 10 minutes, the bulb will turn off.
- To test the Motion sensor.
 - Enter test mode
 - Power on
 - Toggle switch between moon and sun/moon 4 times until light turns off
 - The lamp will continuously detect motion and will turn off after 2 seconds when motion is detected.
 - After turning off, the lamp will wait for 4 seconds before detecting motion again.
- Exit test mode
 - 2 minutes after entering Test mode, the lamp will automatically enter Normal mode (10 min delay) using the sun/moon setting that the switch is set to.
 - Power off and Power on.