INSTALLATION AND USER GUIDE



Only the fingerprint profile will be encrypted and stored locally on the device

Before returning to the store, call Hubspace Customer Service

TOLL FREE HELP LINE 1-877-592-5233 HOMEDEPOT.COM/HUBSPA

8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

LIMITED LIFETIME MECHANICAL AND 1 YEAR FLECTRONIC WARRANTY

etailer neither assumes not authorizes any representative or other person to assume for it any obligation or liability other than such as is expressly set forth herein. This limited warranty ives you specific legal rights, and you may also have other rights which vary from state to state.

1 YEAR I IMITED WARRANTY

SMART PLUG WARRANTY

This product is guaranteed to be free of defects i

does not include normal wear and tear

WIRELESS PROTOCO

The Wi-Fi CERTIFIED™ Logo is a certification mark of Wi-Fi Alliance®. Apple and the Apple logos are trademarks of Apple. Inc., registered in the U.S., and other countries. App Store is a service mark of Apple Inc. Google, Google Play and the Google Play logo are trademarks of Google LLC.

e Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG.inc. and any use of such marks by The Home Depot. Inc., is the standard the product conforms to under license. Other trademarksand trade names are those of their respective owners.

Smart Plug QDID 153778 and 141499

ais device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

E. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. Thes Drive-in Collar (Option its are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and The product is made of mechanical and electronic components, which may be sensitive towards water, physica can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful impact, and electric shock. Using the product with care prevents unexpected malfunction and optimizes the erence to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to corre product life span.

interference by one or more of the following measures leorient or relocate the receiving antenna.

is device complies with Part 15 of the ECC Rules. Operation is subject to the following two conditions:

- Increase the senaration between the equipment and receiver
- Consult the dealer or an experienced radio/TV technician for help

This device complies with Industry Canada licence-exempt RSS standard. Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

his equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed

and operated with a minimum distance of 20cm between the radiator and any part of your body

10256A-LA02303B

424 Buford Business Blvd NE Ste 100 Buford, GA 30518 1-770-441-2830

Please Read This Notice Before Installing, Using, and Servicing the Produc The product is designed and manufactured for providing security. Please read carefully and follow the instructions given below. Lack of proper working knowledge or improper use could cause unexpected Exterior Assembly damage or loss to personal or commercial belongings.

- Mounting Plate Please contact your local service provider prior to the installation as your door preparation may be different from
- Any removal or replacement of parts in installation is NOT recommended and may invalidate the warranty of the

- ALWAYS use authentic alkaline batteries. It is the user's responsibility for damage caused by using
- DO NOT disassemble the product without advice from qualified service provider. Unauthorized disassembly will void the product warranty

Service and Maintenance

Not to be used on an Emergency Exit

- connect the equipment into an outlet on a circuit different from that to which the receiver is connected Please refer to TROUBLESHOOTING page if any problem occurs, or contact your local service provider for professional instructions.
 - Remove all batteries from the lock at the same time and replace them with new batteries of the same size and type Preserve battery and lock life by removing the batteries when the lock is not being used for more than 3 months

ALWAYS seek advice from your local service provider on cleaning, moving, or maintaining the product.

The information in this notice is subject to change without notice.

Make sure to use this product together with 10A circuit breaker in the upstream.

B | 13/16" (20 mm) Screw

C 3/4" (19 mm) Wood Screw For indoor use only. Do not use in wet locations. The total current limit of the device is 10 Amps. To avoid damage, do not exceed the 10 Amp limit. If a direct short is created on the output, the Smart Plug will be damaged and no longer function. Do not disassemble the product or make repairs yourself. You run the risk of electric shock and voiding the limited warranty. If you need service, please contact Customer Support.

Power Cable

- Interior Assembly

- Smart Plug


AA | 1-13/16" (46 mm) Mounting Bol

Package Contents Lis

Hardware Contents (Actual Size)

Part Description

2		
2	⊕	_
4	/	




Safety Information

do not attempt to assemble, install or operate the product. Call the Customer Service Team or visit Read the precautions and instructions in this manual before installing and using this lock.

Save this manual for future reference.

- B. Do not drop or hit the lockset. Too much shock may result in permanent damage Do not use pins or sharp objects to press the keypad. D. Always create a backup of information you wish to keep (Admin PIN, User PIN, etc.)
- E. Restrict access to your lock's interior assembly and routinely check your settings to ensure they have not been altered without your knowledge




A. Remove locks, or do not install locks, prior to painting your door B. Periodically clean with mild soan and a soft cloth only.

avoid using sharp or abrasive objects to clean this lockset. D. Do not allow any water or liquids into the lockset during installation

> If the door needs to be drilled, please be familiar with how to use a drill safely and understand all of the door preparation steps before proceeding


Before Proceeding

Check Dimensions Adapter col




Step 1: Drill Door For New Installation











For 2-3/4" (70 mm) backset: 3-13/16" (97 mm)

Prepare the door jamb – use the strike plate as a template to drill the latch and screw holes and chisel out the mortise. The strike plate must fit flush with the surface of the door jamb






Step 2: Install the latch and strike







Set the latch backset


2-3/8" (60 mm)
























into connector port.

Note: The metal connector


side should face outward.




The cable must be arranged

as shown in the diagram.











Go to the device settings in the app and set up Wi-Fi again. Check that your WiFi Access Point is allowing the device to join the network.








Set up Wi-Fi for the product. If you have already set up Wi-Fi for this product, wait for it to connect. Check the Hubspace app for connectivity status.



your devices, please check your router settings or move your product closer to your Wi-Fi router.





+" button in the upper right corner to add your lock by scanning QR code on the lockset or in Lock Quick Set up Smart Plug as Wi-Fi Gateway for remote control.

> device" to setyour Smart Plug as a Wi-Fi Gateway. This allows you to connect your lock remotely with internet access from your phone.

> > Wi-Fi Gateway Setup









You can connect your smart plug to Google Home and Alexa from the Hubspace app. Or, you can sign in to Alexa app or Google Home and connect to your Hubspace devices from there.


If the QR code cannot be scanned, you can enter the code manually. Tap Enter Code and follow the














NOTE: Double check your product for the correct hole sizes









– Ø 2-1/8" (54 mm)

Ø 1-1/2" (38 mm)

1-3/4" 1-9/16" 1-3/8"

(51 mm) (45 mm) (40 mm) (35 mm

2-3/4" (70 mm)