

20-Inch Artificial Eucalyptus Wreath Use and Care Manual

1. Introduction

This manual provides guidance on the proper use, installation, and maintenance of the 20-inch artificial eucalyptus wreath (with a plaid burlap bow included). Following these instructions will help preserve the wreath's appearance and extend its service life, ensuring it remains suitable for indoor and outdoor decoration scenarios — such as front doors, windows, porches, farmhouses, terraces, and gardens—throughout all seasons.

2. Use Instructions

2.1 Preparation

Unpack the wreath and bow carefully. Remove all packaging materials (e.g., plastic wraps, foam padding) to avoid scratching the artificial leaves or damaging the bow.

Before use, check for any loose components (e.g., detached leaves, loose bow strings). If found, gently reattach them by hand; no glue is required unless specifically noted.

2.2 Installation & Placement

2.2.1 Indoor Use

For windows or indoor walls: Use a non-marking adhesive hook (not included) or a small nail (to avoid surface damage) to hang the wreath. Ensure the hook or nail can support the wreath's weight (approximately 0.5-1 lb).

For tabletops or shelves: Place the wreath on a flat, stable surface. A small decorative base (e.g., a wooden tray) can be used to prevent slipping.

2.2.2 Outdoor Use

For front doors or porches: Use a weather-resistant hook (e.g., outdoor-specific metal or plastic hooks) to hang the wreath. Keep it 2-3 inches away from door edges to avoid friction when opening or closing the door.

For terraces or gardens: Use a thin, durable rope (not included) to tie the wreath to railings or tree branches. Choose an installation spot sheltered from direct strong winds (e.g., avoid exposed high platforms) to prevent the wreath from being blown off.

Adjust the bow: After installation, gently arrange the bow to keep it centered and wrinkle-free. Do not pull the bow strings too hard, as this may cause tearing.

3. Care Guidelines

3.1 Daily Cleaning

Regular dust removal: Use a soft, dry microfiber cloth or a feather duster to gently wipe the artificial leaves and bow. Avoid hard brushes or abrasive materials, as they may scratch the leaf surface or fray the bow fabric.

Light stain treatment (e.g., dust on leaves): Dampen a soft cloth with clean water (no soap or detergent) and gently blot the stained area. Immediately pat dry with a dry cloth to prevent water from seeping into the leaf base, which could cause discoloration.

3.2 Seasonal Maintenance

3.2.1 Summer (High Temperature & UV Exposure)

If hung outdoors, avoid prolonged direct sunlight (more than 6 hours per day). Long-term UV exposure may cause the leaves to fade. During peak sun hours, consider moving the wreath to a shaded area (e.g., under a porch awning).

3.2.2 Winter (Moisture & Frost)

In rainy or snowy weather, temporarily remove the wreath from outdoor locations to prevent

water accumulation on the leaves. Accumulated water may cause the leaf material to harden or crack in frosty conditions.

If the wreath gets wet accidentally, shake off excess water and air-dry it in a well-ventilated area. Avoid direct heat sources (e.g., heaters), as they may warp the leaves.

3.3 Storage

When not in use (e.g., after a season), first clean the wreath following the steps in Section 3.1.

Store the wreath in a dry, cool place. Use a breathable dust bag or a cardboard box (lined with tissue paper to prevent friction) to protect it from dust and pressure. Do not stack heavy items on top of the stored wreath.

If needed, store the bow separately: Gently remove the bow, fold it softly, and store it with the wreath to prevent creasing.

4. Important Precautions

Do not immerse the wreath in water or wash it with a hose. Excessive moisture will damage the artificial leaves and bow.

Keep the wreath away from sharp objects (e.g., scissors, nails) to avoid tearing the leaves or bow fabric.

Do not place the wreath near high-temperature sources (e.g., candles, fireplaces, heaters), as the artificial leaf material may melt or deform.

This wreath is for decorative use only. Keep it out of the reach of pets and small children to prevent them from chewing or pulling the leaves.