



IMPORTANT SAFETY INSTRUCTIONS

English



MODEL #: HVCF 4000

THE PORTABLE POWERFUL AIR MOVEMENT MACHINE

For Your Safety Read And Save These Instructions

Please read these important safety instructions and warnings before operating your Blower. Use Blower in accordance with the safety instructions and warnings described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injuries to persons. Do not throw these instructions away, keep them for further reference.



Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-800-433-1626

USER INSTRUCTION MANUAL


READ AND SAVE THESE INSTRUCTIONS

CAUTION: Do not operate this blower fan with a damaged cord or plug. Discard this blower fan or return to an authorized service facility for examination and / or repair.

CAUTION : Do not run cord under carpeting. Do not cover cord with throw rugs, runners or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.


IMPORTANT SAFETY INSTRUCTIONS

Before operating read and understand this manual and all the blower labels. When using your blower, follow basic safety precautions including the following:


 **CAUTION:**
To reduce the risk of fire, electric shock or injury:

- If your blower does not work, miss parts, was dropped, damaged, left outdoors or dropped into water, return it to an Authorized Service Center.
- Do not put any object into ventilation openings. Do not operate with ventilation openings blocked; keep free of dust, lint hair or anything that may hinder the air flow.
- Keep hair, loose clothes, body parts away from openings and moving parts.


 **CAUTION:**
Extreme caution is necessary when the blower is used near children.

 **WARNING:**
To reduce the risk of fire, electric shock or injury:

- To reduce the risk of electric shock, do not expose to rain. Store indoors.
- Unplug unit from outlet when not in use and before servicing. Turn off blower before unplugging.
- Do not use this air blower with any solid state speed control device.
- Automatically operated protective device. To reduce the risk of injury, disconnect from power supply before servicing or cleaning.
- Do not yank on cord. To unplug grasp the plug, not the cord.
- Do not use with damaged cord, plug or other parts.
- Do not pull or carry by cord, use cord as handle, pull cord around sharp edges or corners.
- Keep cord away from heated surfaces.
- Do not handle plug or the air blower with wet hands.

 **WARNING:**
To reduce the risk of fire or explosion:

- Do not use or store near hazardous or toxic materials.
- Do not operate this blower near flammable or combustible liquids, explosive dust or gases like gasoline or other fuels, lighter fluid, cleaners, oil-based paints, natural gas, hydrogen, coal dust, magnesium dust, grain dust or gun powder.

 **CAUTION:** To reduce the risk of electric shock:
Connect to a grounded electrical outlet.
Do not use an extension cord with this blower.



The operation of any air blower can result in foreign objects being blown in the eyes, which can result in severe eye damage. Always wear safety goggles complying with EN code. Everyday glasses have only impact resistant lenses, they are not safety glasses. Glasses or goggles not in compliance with European standards can seriously hurt you.



To reduce the risk of hearing damage, wear ear protectors if in the vicinity of where a blower is operating for an extended period of time, or when using it in a noisy area.

 **WARNING: Do not let Fingers touch the plug terminals when installing or removing the plug from the outlet.**

 **WARNING: If not properly grounded, this blower can cause an electrical shock especially when used in damp locations.**

USER INSTRUCTION MANUAL

READ AND SAVE THESE INSTRUCTIONS

Introduction

The blower is designed to move large volumes of air. It can either be used to dry wet carpets, floors and furniture, even the hard to reach or provide moisture control and even excellent air circulation.

The plug supplied with your blower may not fit into the outlet you plan to use. Your local electrical code may require different power cord plug connections. In this case please refer to and make the necessary adjustments before plugging. This blower comes with an electric cord with a grounding plug. Do not modify the provided plug. If it does not fit the outlet contact a qualified electrician. If the power cord is worn out, cut or damaged, do not try to operate the blower and contact a qualified electrician.

Improper connection can result in an electric shock. The green insulated conductor (with or without yellow stripes) is the equipment grounding conductor. If repair/replacement of the electric cord/plug is necessary, do not connect the grounding conductor to a live terminal.

Unpacking & Checking Carton Contents

Carefully unpack and check your air blower. If any parts are damaged or missing, please call your local dealer.

Features & Operation

Level the blower out of the carton and pull off the protective plastic bag. With a soft cloth remove the packing lint if any. Uncoil the power cord then, connect the plug to an appropriate outlet. Your blower is ready to use. Just place the blower in the desired operating position (see below).

Warning:

To move the blower grasp the handle. Do not yank on the cord to avoid any electric shock and/or damage.

This blower has three speeds, and as seen in figure1.

Figure 1



CAUTION: Do not immerse this blower in water, as it can cause electrical shock.

Turning the Blower on

To turn the blower on, just turn switch to the High (3), Med (2) or the Low (1) setting
To turn it off, just turn the switch to the Off (0) position.

Setting the ventilation position

The blower is designed to work on three positions: 0° , 45° & 90° (fig. 2, 3 & 4).



Figure 2



Figure 3



Figure 4



Cord wrap

Maintenance

1. Inspect the electrical cord and the wiring for damage or discoloration.
2. Clean screens on the side and the front of the unit.
3. Listen for abnormal sounds.
4. Keep the unit clean.
5. Make sure the ground pin or grounding prong is intact or the blower will be unsafe to operate.

Periodic Maintenance

Use compressed air or vacuum to remove lint, dust ect, from motor, screens or blower wheel. Do not use a pressure washer to clean the unit.

Trouble Shooting

Problem	Solution
The Blower unit won't run.	<ol style="list-style-type: none">1. Ensure that The Blower unit is securely plugged into outlet or power source.2. Check that outlet or power source is receiving power.3. Check that The Blower unit is turned on.

PRECAUTION: Always consult a professional technician, qualified electrician or your dealer for accessing the internal of the unit.

WARNING:

This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety. Children should be supervised to ensure that they do not play with the product.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

VENTAMATIC, LTD. LIMITED WARRANTY

This warranty is underwritten by Falco Insurance Company and is extended to the original retail purchaser of this model or, if this unit is purchased and requires installation by a building contractor, to the original owner of the home. No subsequent purchaser of the unit or of a home in which it is installed is entitled to any of the benefits of this warranty.

This product is warranted against defects in materials and workmanship for a period of one (1) year from the date of original retail purchase. No other parts or components are warranted. There is no warranty for defects caused by abuse, faulty installation, or the like.

Repairs or replacement parts supplied under this warranty are warranted only for the period of this warranty; that is, one (1) year from the date of the original retail purchase of the unit. In the event of a defect or malfunction, we will replace or repair the defective part or component only and return the new or repaired part to you freight prepaid.

You must bear all other expenses incurred in obtaining repairs, including labor required for field repair or replacement, and the cost of shipping the defective part to us. You must also bear the cost of repair to or replacement of any part or component and the shipping charges incurred for the repair or replacement and return to you of any part or component not covered by this warranty, including parts or components damaged by you.

The company reserves the right to demand and receive written evidence of the date of purchase before undertaking its obligations under this warranty. The right to demand and receive written evidence of date of purchase extends to all licensed dealers of Ventamatic, Ltd. products. You should, therefore, retain your sales slip and attach a copy of it to the warranty claim.

**To start a warranty claim you must:
Contact Ventamatic, Ltd.**

An RGA (Returned Goods Authorization) form is required for returns to the factory to ensure your return can be processed efficiently and quickly. Please contact Ventamatic, Ltd. toll-free at 800-433-1626 or via web at www.MYMAXXAIR.com to obtain an RGA and follow the instructions given.

There is no informal dispute settling mechanism available in the event of a controversy involving this warranty.

Any and all implied warranties which may exist terminate upon the expiration of this warranty one (1) year from the date of the original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so this limitation may not apply to you. Ventamatic, Ltd. is not liable to you for incidental or consequential damages arising out of defect or malfunction of a unit or its installation or out of any alleged breach of this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so this limitation may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

rev. 4/19