


REPLACEMENT PARTS - BDXGVAM212101

2-CYCLE CULTIVATOR

PPN 21AK225C936




Item	Part No.	Description	Item	Part No.	Description
1	791-181862	Screw	20	753-06275	O-Ring
2	791-181345	Screw	21	753-06840	Module
3	753-06833	Rear Housing (includes 1 & 2)	22	753-06841	Shortblock (includes 5, 6, 20 & 21)
4	753-06792	Muffler	23	914-04016	Flywheel Key
5	753-06847	Spark Plug	24	753-06175	Flywheel
6	791-182723	Screw	25	753-06247	Washer
7	753-06184	O-Ring	26	753-08404	Starter Housing
8	753-06189	Insulator Assembly (includes 7)	27	753-06218	Spacer
9	753-06185	O-Ring	28	753-05860	Clutch Assembly
10	753-06190	Carburetor	29	753-06843	Clutch Cover
11	753-06253	Gasket	30	712-0161	Nut
12	753-11175	Air Cleaner Base	31	710-05401	Screw
13	710-04517	Screw	32	9689A	Screw
14	753-06835	Plate	33	791-181345	Screw
15	753-06836	Filter	34	735-04278	Spacer, Rubber
16	753-06837	Air Cleaner Cover	35	753-06846	Fuel Tank (includes 37)
17	753-06838	Knob	36	791-181930	Fuel Tank Screw
18	753-06174	O-Ring	37	753-06857	Fuel Tank Cap
19	753-06839	Lead Wire			

REPLACEMENT PARTS - BDXGVAM212101

2-CYCLE CULTIVATOR

PPN 21AK225C936



Item	Part No.	Description
38	720-0294A	Foam Grip
39	753-05940	Spring
40	753-06808	Throttle Control
41	753-06319	Handle
42	791-182405	Switch
43	753-06831	Throttle Cable
44	735-04246	Cap
45	10591	Rope Guide
46	712-04064	Nut
47	791-182899	Bolt
48	936-0451	Washer
49	791-182677	Knob
50	753-06809	Handle
51	753-06813	Upper Bracket
52	710-3013	Screw
53	710-1026	Bolt
54	936-0451	Washer
55	912-3027	Nut
56	753-06814	Lower Bracket
57	753-06817	Square Tube
58	714-04106	Clevis Pin
59	714-0104	Cotter Pin
60	726-0299	Cap
61	753-04437	Wheel (includes 60)
62	791-182910	Washer
63	753-06815	Spacer
64	753-06816	Axle
65	753-06811	Clip
66	753-05983	Tine (Left Inner, Right Outer)
67	753-05984	Tine (Left Outer, Right Inner)
68	791-182195	Screw
69	753-06063	Gearbox (includes 68)
70	710-0599	Screw
71	753-04499	Flex Shaft
72	753-06812	Tube (includes 71)
73	753-06810	Shield