

OVENTE®

13-Inch Ceramic Pizza Stone Set BW10132 Series



Before using, please read the instruction manual and keep it for future use.



NCH CERAMIC PIZZA STONE SET

Made of ceramic, this Pizza Stone absorbs excess moisture and distributes heat evenly to produce uniformly browned pizza crust. It comes with a pizza cutter wheel with finger protection that provides optimal stability and excellent security grip, and a versatile metal handles that can be used as a rack for safe and easy transport to serving table.

The Pizza Stone is compatible with a conventional or microwave oven for baking bread, biscuits, tortillas, pretzels, bagels, cookies and rolls. It's terrific for heating and reheating ready-made pizzas and baked goods.

The Pizza Stone retains heat to keep food warm for serving, and it requires no seasoning or conditioning.



IMPORTANT SAFEGUARDS

When using the Pizza Stone, basic safety precautions should always be followed to prevent risk of fire, burns, or other injuries and damages.

- Before using, remove all packaging materials from the Pizza Stone.
- Do not place the stone over an open flame, or in broiler.
- Do not use flour as it will burn on the stone.
- Do not cut pizza directly on the stone.
- Handle the stone with care to prevent chipping or breaking.
- The Pizza Stone retains heat, always wear oven mitts while handling.
- Close supervision is necessary when the Pizza Stone is used and near children.
- This Pizza Stone is not intended to be used by persons (including children) with reduced physical, sensory and mental capabilities. It is not for persons with lack of experience and knowledge, unless they have been given supervision or instructions concerning the use of the cookware by a person responsible for their safety.
- Quick changes in extreme temperature could cause thermal shock, causing your stoneware to crack. Make sure the stoneware has cooled to room temperature before washing or placing in the oven.
- When serving, use the serving rack to avoid heat damage to countertops or table surfaces.
- Before cleaning, allow to cool completely.
- Do not use soap or any other detergent when cleaning, as the stone is porous and will absorb its taste.
- Do not clean the Pizza Stone in the dishwasher.
- The Pizza Stone will darken gradually and retain some staining over time. It's a part of the stone's natural seasoning and will not harm or affect the taste of the food.
- Do not use outdoors or for purposes other than intended use.
- **CAUTION:** This item generates heat during use. Proper precautions must be taken to prevent the risk of burns, fires, or other damages to property caused by touching the parts while in use or during cooling.



ING THE PIZZA STONE

IMPORTANT: Avoid extreme temperature changes. Do not place a cold stone in a hot oven, or a hot stone on a cold countertop.

- 1) Rinse in warm water before first use and allow to dry thoroughly.
- 2) Preheat it by placing unheated stone into a room temperature oven.
- 3) Set the oven temperature.
- 4) Prepare your food while preheating the stone.
- 5) Place the food on the preheated stone. Because stone retains heat, always wear oven mitts while handling.
- 6) When done cooking, Turn OFF the oven, remove your food from it, but leave the pizza stone in the oven until it is entirely cool.



CARE AND MAINTENANCE

IMPORTANT: Make sure the stoneware has cooled to room temperature before washing. Quick changes in extreme temperature could cause thermal shock, causing your stoneware to crack.

IMPORTANT: Do not clean the Pizza Stone in the dishwasher.

- Before cleaning, allow the Pizza Stone to cool completely.
- Remove baked on food, and rinse with warm water.
- Do not use soap or any other detergent when cleaning, as the stone is porous and will absorb its taste.
- Let stone air dry thoroughly before using again.
- Do not use oven cleaners, scouring pads or harsh abrasives on your stoneware.



WARRANTY

Register your product within 30 days of purchase to activate its one-year limited manufacturer's warranty at [ovente.com/register](https://www.ovente.com/register)

LIMITED ONE (1) YEAR WARRANTY

Your product has a one (1) year warranty period from the date of purchase from an authorized retailer. This warranty only covers defects in workmanship and materials. The warranty does not include damage due to abuse, misuse, commercial use, accidents or natural wear and tear. In case of replacement, shipping and handling fee may apply.

LIMITATIONS

The warranty stated above is the only warranty applicable to this product. Other expressed or implied warranties are hereby disclaimed. No verbal or written information given by the Manufacturer, its agents or employees shall create a guarantee or in any way increase the scope and duration of this warranty. Repair or replacement as provided under this warranty is the exclusive remedy of the consumer. The manufacturer shall not be liable for incidental or consequential damages resulting from the use of this product. Any implied warranty of merchantability or fitness for a particular purpose on this product is limited to the applicable warranty period set forth above except to the extent prohibited by law. Proof of purchase may be required to validate the order. Promotional items may not be covered under any warranty. Consumer rights may vary from state to state.

Customer Support:

[ovente.com/support](https://www.ovente.com/support)

+855.926.2626

Visit us at [ovente.com](https://www.ovente.com)



[Facebook.com/ovente](https://www.facebook.com/ovente)



[@OventeTweets](https://twitter.com/OventeTweets)



[@Ovente](https://www.instagram.com/Ovente)



[youtube.com/ovente](https://www.youtube.com/ovente)

