

HOME DECORATORS COLLECTION®


HANGTAG REMINDER



For More Troubleshooting
Information, Scan QR Code


Section Out?

Push & Rotate




Not Full?

Spread Branches




No Lights Working?

Check for loose connection



Branch Hanging Low?

Bend up



Other Issue?



Call

1-877-527-0313