


This LED tube is intended to replace fluorescent tube lamps with an ANSI designation 32W/23T8/U6 (ONLY)



Questions?

For customer service please call us at 1-888-743-5766
Office Hours: 8:00 a.m. – 5:00 p.m. PST Monday-Friday



U-Bend
LED T8 Lamp
Direct Replacement


PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION

WARNINGS	CAUTIONS
<ul style="list-style-type: none"> • Risk of fire • Ballast is required for proper operation. • For ballast compatibility list visit: www.eurilighting.com • Risk of electric shock – disconnect power at source before installation • Do not make or alter any open holes in an enclosure of wiring or electrical components during installation. • Do not install this lamp into a pre-heat luminaire. • If lamp or luminaire exhibits abnormal operation (buzzing, flickering, minimal light, etc.), turn off power, remove lamp and contact us. For more information please visit www.eurilighting.com or call our toll-free number 1-888-743-5766. 	<ul style="list-style-type: none"> • Do not use with dimmers. • Do not look directly at the operating LED lamp. • Do not touch this product with wet hands. • Do not disassemble, repair or alter lamp. • Designed for indoor applications only. • Suitable for damp locations. • The luminaires shall be grounded. • Avoid contact with lamp pins during installation. • To prevent early lamp failure: Lamp should only be installed in operating environments ranging between -20° C and +50° C . • This Device is not intended for use with emergency exits or emergency lights.

DIRECT REPLACEMENT INSTALLATION INSTRUCTIONS


1. Turn-off power before installation | 2. Replace traditional fluorescent tube with LED tube | 3. Turn-on power and enjoy your new LED tube.

STEP 1




Turn-off power

STEP 2a




Open cover for access.

STEP 2b




Remove existing lamp

STEP 2c




Insert new LED U-Bend Lamp and ensure it is secured.

STEP 2d



Close cover after installation is completed.

STEP 3



Turn-on power

NOTE: Ballast required for operation.

