




Replacement Parts List

Teapot 4 in. Centerset 2-Handle Low-Arc Bathroom Faucet in Brushed Nickel

MODEL	Internet SKU #	FINISH
HD67092W-6204	300640763	Brushed Nickel



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Index C	RP1000204		
2	Set screw	RP50005		
3	Handle seat	RP1702704		
4	Retainer	RP1313604		
5	Handle C	RP13005		
6	Cap & bolt	RP1300604		
7	Inverter	RP64044	206671349	
8	Bonnet nut	RP70193	206671342	
9	Washer	RP64123		
10	Cartridge H	RP20067	301158139	

Part	Description	Part #	Internet SKU #	Store SKU #
11	Cartridge C	RP20068	301158129	
12	Mounting nut	RP56001	203193994	579276
13	Index H	RP1000104		
14	Handle H	RP13004		
15	Aerator	RP3021004		
16	Lift rod	RP4020404		
17	ClickInstall™ drain assembly	RP4022804		
18	Gasket	RP80182		