


# **USE AND CARE GUIDE**

### **2 DRAWERS CONSOLE TABLE**



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service. 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

### 1-800-998-7021

### HOMEDEPOT.COM/HOMEDECORATORS

#### THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this 2 drawers console table. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

### **Table of Contents**

Table of Contents	2
Safety Information	2
Warranty	2
3 Year Warranty	
What is Covered	2
What is Not Covered	2
Pre-assembly	3
Planning Assembly	3
Tools Required	3

### **Safety Information**

# 

- □ Keep small parts away from children during assembly.
- □ Read and follow instructions carefully.

# 

- □ Read these instructions carefully and keep in a safe place.
- □ TO GUARANTEE THE SAFE USE OF THIS PRODUCT, FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL.
- □ Adult assembly required.
- □ Small parts may present choking hazard prior to assembly.
- $\hfill\square$  Do not place heavy objects on the glass top.
- □ Some assembly may involve attaching glass or mirrors.
- Be very careful handling the glass or mirrors, as severe injury may result if the glass or mirror breaks.
- □ Never handle large pieces of glass or mirrors by yourself.

### Warranty

### **3 YEAR WARRANTY**

### WHAT IS COVERED

We guarantee this product to be free of manufacturing defects to the original purchaser for three years.

### WHAT IS NOT COVERED

This warranty does not cover commercial use, acts of nature, and abusive use.

Hardware Included	3
Pre-assembly (continued)	4
Package Contents	4
Assembly	5

### 


- Do not use power tools to assemble your furniture. Power tools may strip or damage parts/product.
- Do not overtighten connectors (screws, bolts, etc.).
  Overtightening can lead to product damage.
- Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact THE HOME DEPOT to obtain any missing parts.
- DO NOT USE SUBSTITUTE PARTS.
- □ This product should only be used on a flat, level surface.

### **Pre-assembly**


### **PLANNING ASSEMBLY**

Keep children and pets away from build area. Make sure your area is large enough to unpack, sort and assemble the unit.

### **TOOLS REQUIRED**




#### **HARDWARE INCLUDED**



Part	Description	Quantity
AA	Wood dowel	16
BB	Cam lock bolt	20
CC	Cam lock	20
DD	1 in. Flat head screw	20
EE	1-1/2 in. Flat head screw	2
FF	Handle	2
GG	Handle bolt	4
HH	Anti-tipping hardware package	1

# **Pre-assembly (continued)**

### **PACKAGE CONTENTS**




Part	Description	Quantity
Α	Top panel	1
В	Left side frame	1
C	Right side frame	1
D	Partition	1
E	Fixed panel	1
F	Top crossbar	1
G	Back panel	1

Part	Description	Quantity
Н	Bottom crossbar	1
I	Drawer front panel	2
J	Drawer left side panel	2
K	Drawer right side panel	2
L	Drawer back panel	2
М	Drawer bottom panel	2


# Assembly


### Attaching the partition to fixed panel


a) Join partition (D) to panel (E) with dowel (AA).



**b)** Tighten panel (E) with screw (DD).









### Attaching the right side frame and top crossbar


a) Install dowel (AA) and bolt (BB) into frame (C). 



c) Join frame (C) and bar (F) to the assembled body with dowel (AA).




d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes. 




# Attaching the left side frame and bottom crossbar


a) Install dowel (AA) and bolt (BB) into frame (B).



□ c) Join frame (B) and bar (H) to the assembled body with dowel (AA).




d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.
 Tighten bar (H) with screw (EE).



 $\hfill\square$  b) Insert lock (CC) into panels (E) and (G), bar (F).


### Attaching the top panel

a) Install dowel (AA) and bolt (BB) into panel (A). 





b) Insert lock (CC) into frames (B) and (C), panel (G) and partition (D).

c) Join panel (A) to the assembled body with dowel (AA). 




d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes. Tighten bar (F) with screw (DD).






# $\mathbf{7}$ Inserting the drawer


□ Insert the drawer into the assembled body as shown.




# ${\bf 8}\,$ Finalizing the assembly

□ Install the anti-tipping hardware as shown.







 Rectangle	1/2 in. Flat head screw	Plastic anchor	Plastic band	1-1/2 in. Flat head	Small head
metal plate				screw	
( <b>1</b> ) x 2	( <b>2</b> ) x 1	( <b>3</b> ) x 1	( <b>4</b> ) x 1	( <b>5</b> ) x 1	
() ()	ALLE CONTRACTOR	and O			—HH



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service. 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

#### 1-800-998-7021

#### HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.