

## **Contents:**

- **4 - 48" 18 AWG Wires**
- **4 - Electrical Connectors**

**CAUTION: Turn off electrical current at source before working with any lighting fixture or ceiling fan. Install and use this product according to your local electrical codes and regulations.**

1. Connect wires from ceiling fan to wire extenders by using wire connectors.
  2. Wire connectors should be installed with insulated crimping tool. Connections should be made in down rod.
  3. Thread wires through down rod.
  4. Connect free ends to wires in electrical box making sure wire color matches throughout system.
- 

## **Contenido:**

- **4 - Cables de 1,22 m (48") de Largo, AWG, de 18 Indicios**
- **4 - Conectores de Cable**

**PRECAUCIÓN: Apague la corriente eléctrica en la fuente de abastecimiento antes de trabajar con cualquier adorno de iluminación o ventilador de techo. Instale y use este producto siguiendo los códigos y reglamentos locales de electricidad.**

1. Conecte los cables del ventilador de techo a los prolongadores de cables usando conectores de cable.
2. Los conectores de cable deben ser instalados con tenacillas con aislamiento. Las conexiones se deben hacer en la varilla descendente.
3. Enroscar los cables por la varilla descendente.
4. Conecte los extremos que estén sueltos a los cables de la caja de empalme, asegurándose que los colores de los cables hacen juego en todo el sistema.