Brio

HYDRATION INNOVATION

Step-by-Step Guide to


Changing Your Filter


Applies to the Following Models:
ROSL500, ROSL500WHT, ROSL700,
ROSL700BLK, ROSL700WHT

1. Replace Filter

When one or both of your filter indicator lights begin to flash, the filter(s) need to be replaced. To change filter:

1. Unplug unit from power source, then turn off water supply. Open faucets and drain remaining water in system. Remove compartment cover of filter to be replaced.
2. Grasp handle of expired filter and rotate counterclockwise to unlock from compartment. If you encounter resistance, use filter release tool (A). Once expired filter has been unlocked, remove from compartment.
3. Insert new filter, rotating clockwise to lock into place. Filter handle should align with dot as shown in the below illustration. Reinstall compartment cover.
4. Turn on water supply, then plug unit back into power source. Press and hold the reset button **(1)** until filter indicator light stops flashing (approximately 3 seconds). Proceed to "Flushing the Filters" section.





2. Flushing the Filters

Always flush new filters before using. Open faucet. Press the flush button (2) once. The flushing process takes approximately 60 seconds. To stop the flushing process at any time, press the flush button again.

NOTE: The flush button does not work when the system is in an automatic flushing mode.