

Installation Guide

1. Unpack the canopy frame and fabric top from the carrying bag.
2. Place the frame upright on level ground.
3. With two people, gently pull the frame outward until it is halfway open.
4. Drape the canopy top over the frame, aligning corners with the frame's Velcro straps.
5. Fully extend the frame legs until the locking mechanisms click.
6. Attach the canopy top securely using Velcro straps at each corner.
7. Install sidewalls by attaching hooks and Velcro along the canopy edges.
8. Adjust leg height to desired position and secure with pins.

Instructions / Assembly

- Always assemble with at least two adults.
- Do not force any locking joints.
- Ensure all push-buttons and sliders engage fully.
- Use stakes or weight bags to secure the canopy in outdoor settings.

Replacement Part List

- Canopy Fabric Top (Black)
- Sidewalls (x2)
- Pop-Up Frame Assembly
- Leg Extension Pins
- Velcro Straps Set
- Stakes (x4)
- Carrying Bag

Use and Care Manual

- Clean canopy fabric with mild soap and water only.
- Allow to fully dry before storing to prevent mildew.
- Store indoors during severe weather or long periods of non-use.
- Do not leave canopy unattended in strong winds.
- Inspect frame joints and fabric before each use.