LP-2400-00
UNIVERSAL PAIL SHELF
ASSEMBLY INSTRUCTIONS

NOTE: READ INSTRUCTIONS CAREFULLY BEFORE STARTING ASSEMBLY.

WARNING: Follow instructions carefully. If further assistance is necessary, contact
Louisville Ladder Group, Customer Service at 1-800-666-2811.

Louisville Ladder Inc. • 7765 National Turnpike, Unit 190. • Louisville, KY 40214

Pail Shelf may be used on all model lengths of the following series ladders.

LOUISVILLE	
AS1000	FS1400HD
AS1100HD	FS1500
AS2000	FS2000
AS3000	FS2500
AS4000	FS4000
AS5000	L-2012
FS1000	L-2111
FS1100	L-3012
FS1100HD	L-3013
FS1200	L-3111
FS1300	L-3211

Also works with:
RIDGID: FS1000-800022, FS1500-800022R, R-3011W 540
DAVIDSON: 410, 486, 634, D-3011, D-3013, D3111, D-3211

The following tools will be needed for assembly.
- Standard Flathead Screwdriver
- Pliers

The following parts are included in this package. Please contact your dealer if parts are missing.

Qty.	Description	Item Number
8	Machine Screw 10-24x5/8	F3478-63
8	3/16" Washer	F0418-63
8	10-24 Locknut	F3476-63
2	Pail Shelf Arms	F7513
1	Molded Pail Shelf	F9080-69
1	Pail Shelf Bracket	F5333

Part number F7585

1. INSTRUCTIONS FOR PAIL SHELF ASSEMBLY

For use with: 410, 592, 634, D-3013, D-3211, FS1300, L-3013, L-3211.

Note: This is used for 540 and 486 ladders if they have the "L" shape back brace.
Note: Notice Pail Shelf Arms bend upward.

ILLUSTRATION A

For use with: AS1000, AS1100HD, AS2000, AS3000, AS4000, AS5000, D-3111, D-3011, FS1000, FS1000-800022, FS1100, FS1100HD, FS1200, FS1400HD, FS1500, FS1500-800022, FS2000, FS2500, FS4000, L-2012, L-2111, L-3012, L-3111, R-3011W.
**Note**: This is to be used for 540 and 486 ladders if they have the "Hat" shaped back brace.
**Note**: Notice Pail Shelf Arms bend downward.

ILLUSTRATION B

1. Look at the model label on the side of the ladder to determine the ladder model. Refer to the corresponding illustration (A or B) for your ladder model.
2. Layout parts as shown in the illustration you selected in *step 1*. Pail Shelf Bracket should be beneath Pail Shelf Arms.
3. Line up holes on the Pail Shelf Arms and the Plastic Molded Pail Shelf. Insert washer onto screw then insert screw through the Plastic Molded Pail Shelf and the Pail Shelf Arms. Tighten with locknut.
4. Line up holes on the Pail Shelf Arms and the Pail Shelf Bracket. Insert screw through holes in the Pail Shelf Arms, then the washer and then the Pail Shelf Bracket. Tighten with locknut.

2. INSTRUCTIONS FOR INSTALLATION OF PAIL SHELF

Diagram 1

For use with: 486, 540, D-3111, D-3011, FS1400HD, FS1500, FS1500-800022, FS2000, FS2500, FS4000, L-3012, L-3111.

Diagram 2

For use with: AS1000, AS2000, AS3000, AS4000, AS5000, AS1100HD, FS1000, FS1000-800022, FS1100, FS1100HD, FS1200, L-2012, and R-3011W.

Diagram 3

For use with: 486, 410, 540, 592, 634, D-3013, D-3211, FS1300, L-3013, and L-3211.

1. Choose the corresponding diagram (1, 2 or 3) for the ladder model you own.
2. Line up the pail shelf bracket and the ladder back brace as shown. Holes on the pail shelf bracket and the ladder back brace will line up. NOTE: If there are no holes punched in your back brace use the template provided to drill the holes required.
3. When lining up the pail shelf, make sure that its arms rest beneath the top step of the ladder.
4. Insert screws through holes with the parts aligned as shown in the diagram you selected in step one. Install flat washers and tighten with locknuts.
5. Confirm that all screws and nuts are tightened before use.
6. When closing the stepladder, push downward on the pail shelf arms for the pail shelf to close with the ladder.

Part number F7585