

Sliding Shower Door – Instructions / Assembly Guide

Important Safety Instructions

1. Read all instructions before installation.
2. Keep children and pets away from the work area.
3. Use caution when handling glass to prevent injury.
4. Wear protective gloves and eyewear during installation.
5. Ensure the floor and walls are level and stable before starting installation.
6. Do not force any parts during assembly.

Tools Recommended (Not Included)

- Measuring tape
- Level
- Screwdriver (Phillips and flat-head)
- Drill and appropriate bits
- Rubber mallet
- Silicone sealant

Components Included

- Shower door panels
- Handles
- Mounting hardware (screws, anchors, brackets)
- Rollers and tracks
- Installation guide

Assembly Steps

Step 1 – Prepare the Area

- Ensure shower base or bathtub is clean and level.
- Confirm wall surfaces are finished and dry.
- Check that all components are included in the package.

Step 2 – Install Wall Tracks / Rails

- Position wall tracks according to the desired door orientation.
- Verify tracks are level using a spirit level.
- Secure tracks to the wall using provided anchors and screws.

Step 3 – Install Door Panels

- Carefully place the door panels into the installed tracks.
- Attach rollers or guides to ensure smooth sliding motion.
- Verify that doors slide effortlessly and are aligned properly.

Step 4 – Attach Handles

- Install handles according to the included template.
- Ensure screws are tight but do not over-tighten to avoid damage.

Step 5 – Seal and Finish

- Apply silicone sealant along the edges where the door meets the wall for water protection.
- Wipe off excess sealant and allow it to cure according to manufacturer instructions.

Step 6 – Test the Installation

- Open and close doors several times to ensure smooth operation.
- Check that all components are secure and level.
- Make minor adjustments as needed.

Maintenance

- Clean glass regularly with non-abrasive cleaners.
- Check screws and handles periodically for tightness.
- Lubricate rollers if sliding becomes stiff.

Troubleshooting

- Door does not slide smoothly → Check for debris in track or misaligned rollers.
- Water leakage → Inspect seals and apply additional silicone if needed.
- Handle loose → Tighten screws carefully.