

INSTRUCTION GUIDE

SLIP JOINT NUT



1 Measure and cut wall tube to desired length

2 Position slip nuts and slip washers onto wall tube

3 Insert wall tube into the waste connector and hand tighten the existing waste connector slip nut



4 Position the slip nut and slip washer onto the vertical tailpiece
(Use reducing washer if tailpiece is 1¼")

5 Place J-bend onto the wall tube and tailpiece, and hand tighten the slip nuts for alignment

6 Fully tighten all slip nuts and test for leaks