



your global source for unique lighting + home decor

## ASSEMBLY INSTRUCTIONS

1. Turn off & unplug the light before removing the outer shade to change bulbs.
2. Undo the top locking nut (4) taking care not to lose the washer (3).
3. Lift off the shade and place shade on a clean soft surface to protect from marking.
4. Fit the light bulbs to the lamp holders
5. Place the shade over the light, checking that the washer (3) is in place and refit the locking nut (4)
6. Ensure shade is securely fitted. Plug the light into the socket and switch on


**! CAUTION** - Refer to the wattage caution label located near the lamp holder for maximum wattage - do not exceed the maximum wattage.

**! WARNING** - Do not attempt to replace the bulb(s) while the lamp is plugged into a wall receptacle

**CARE INSTRUCTIONS** - Use only a soft cloth; do not use any chemicals or abrasive cleaners.

## IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit it, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.



E26 Type A.60W X 2 (Not included)

E26 CFL 13W X 2 (Not included)



MADE IN CHINA

