




Replacement Parts List

Teapot 8 in. Widespread 2-Handle Low-Arc Bathroom Faucet in Chrome

MODEL	Internet SKU #	FINISH
HD67738W-6001	300640750	Polished Chrome



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Index H	RP1000101		
2	Index C	RP1000201		
3	Screw	RP50169		
4	Handle assembly H	RP1352601		
5	Handle assembly C	RP1352701		
6	Bonnet nut	RP70435	206864739	
7	Cartridge H	RP20079		
8	Cartridge C	RP20080		
9	Washer	RP64147		
10	Nut & screw	RP56114		

Part	Description	Part #	Internet SKU #	Store SKU #
11	Aerator	RP3019601		
12	Rubber washer	RP64035		
13	Metal washer	RP64036		
14	Lock nut	RP56019		
15	Block	RP70421		
16	O-ring	RP60002		
17	Quick connect hose	RP70430		
18	ClickInstall™ drain assembly	RP4022801		
19	Lift rod	RP4026101		