



Easy Set-up Bike Camping Tent

7ft x 4.5ft x 45in (2.13m x 1.37m x 1.14m)



If any quality problems, feel free to contact us via:
service@unipros.com.cn

Parts list:



- A(1)** Backpack
- B(1)** Rainfly
- C(1)** Tent body
- D(2)** Black Aluminum poles
- E(2)** Golden Aluminum poles
- F(12)** Ground stakes

THIS RECREATIONAL PRODUCT REQUIRES TWO PEOPLE TO ASSEMBLE.

WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS PRODUCT FABRIC.

This product is made of flame-resistant fabric. It is not fireproof. The fabric will burn if left in continuous contact with a flame source.

THIS RECREATIONAL ITEM IS NOT INTENDED FOR USE AS A PERMANENT STRUCTURE.

This product has been developed and is intended to provide protection from sun and light rain. DO NOT use any gas or flame sources under or near this product. This product is NOT WATERPROOF. Excess water build-up can cause the frame system to become unstable, and collapse, causing injury. Any personal accessories or modifications to product should be removed before the onset of inclement weather such as heavy rain, wind, lightning, hail, snow, etc. When hitting golf balls, make sure no humans, animals and properties are behind/close to the tent; do not try full power hitting the balls (not over 120 mph?). This product should be completely dismantled to avoid permanent damage to product components and avoid any possibility of personal injury. This product is not a toy. This product is not designed for use by children without adult supervision. Under no circumstances should this product be used as a permanent or temporary storage facility for children's toys, garden tools, personal belongings or similar valuables. Consumer-made modifications for extended use, ie. permanently securing to decks and patios and/or Consumer's failure to follow stated guidelines, will invalidate any UNIPROS Limited warranty, expressed or implied.

How to Assemble the Bicycle Camping Tent.



- (1) Lightweight backpack for easy carrying.



- (2) Take out all the parts from the backpack and place on the ground for setting up.



- (3) Unfold the tent body. Insert the ground stakes to sturdy the corner of the tent.



- (4) Connect the aluminum poles. Put the aluminum pole in the tent sleeve (orange).



- (5) Cross the two aluminum poles and tie up. Attach J-hook of the tent to the poles to set up the tent.



- (6) Set up the partially camping tent and insert ground stakes to flat the bike parking spot.



- (7) Cover rainfly on the tent. Attach the rainfly to the tent by using hook&loop. Attach the nylon fasteners to the ground stakes to secure the rainfly.



- (8) Attach black poles to the black rubber inlet on the roof tent. Insert black poles to the o-ring inlet on the bottom of the tent. Set two black poles to build the bike tent.



- (9) Use fasteners to strap the bicycle tyre on the pole.



- (10) Withdraw guylines and attach to the ground stakes to enhance and sturdy the whole tent.

Complete the whole set up of the bicycle tent.