



## 6 TON EXTENDED REACH HEAVY DUTY STEEL JACK STANDS

### Pre-Operation \_\_\_\_\_

#### BEFORE ASSEMBLY AND OPERATION

Compare all parts with the Package Contents lists in this manual. If any part appears missing or damaged, do not use this product. Contact the Customer Service Team at 1-888-HD-HUSKY or visit [www.huskytools.com](http://www.huskytools.com).

#### SPECIFICATIONS

Model	Jack Base Dimensions	Max Load Capacity	Lifting Range	Saddle Dimensions	Pair Weight
6 Ton Extended Reach Heavy Duty Steel Jack Stands	11.54 in. x 10.35 in.	12,000 lbs.	15.75 to 24.38 in.	4.22 in. x 1.18 in.	32.19 lbs.