







## USER'S MANUAL

# Inflatable Bounce House

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



# Before You Start

Please read all instructions carefully and keep it for future reference.

## Warnings:

Attention: For home use only.

Attention: The product is not suitable for the children under 3 years

Danger: Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.

Danger: Lack of attachment may cause a risk of tipping or falling hazard.

## General Warnings:

⚠ The product must be installed and used under the supervision of an adult.

⚠ Read through each step carefully and follow the proper order.

⚠ Remove all packaging, separate and count all parts and hardware.

⚠ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.

⚠ We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.

⚠ Ensure a secure surface during installation, and place the product always on a flat, steady and stable surface.

⚠ Please check and maintain it regularly, and the most important part needs to be suspended, fixed, or anchored to the ground.

## ■ INFLATABLE BOUNCER

KEEP THE INSTALLATION INSTRUCTION FOR FURTHER REFERENCE

PLEASE READ ALL OF THE SAFETY RULES BEFORE SETTING UP

We BELIEVE IN SAFETY FIRST. PLEASE FOLLOW ALL OF THE RULES FOR YOUR CHILDREN'S SAFETY

### **WARNING!**

#### **ELECTRICALLY OPERATED PRODUCT**

ADULT SUPERVISION REQUIRED. OPERATING BLOWER (AIR PUMP) NOT RECOMMENDED FOR CHILDREN UNDER 12 YEARS OF AGE. AS WITH ALL ELECTRIC PRODUCTS, PRECAUTIONS SHOULD BE OBSERVED DURING HANDLING AND USED TO PREVENT ELECTRIC SHOCK.

### **CAUTION:**

NOT SUITABLE FOR ADULTS

NOT SUITABLE FOR HIRING OR COMMERCIAL USE

ADULT SET-UP REQUIRED

ADULT SUPERVISION REQUIRED



### **WARNING!**

Not suitable for children under 3 years. Small parts may be swallowed.

### **WARNING!**

ONLY FOR DOMESTIC USE. OUTDOOR USE

TO BE USED ON SOFT GROUND ONLY


## SET-UP

- Check the ground where the product will be set up for any sharp objects or debris. Do not install the product over concrete or any hard surface.
- Place the product on a soft level surface at least EN from any structure or obstruction such as a fence, garage, and house, overhanging branches, laundry lines or electrical wires.
- Ensure the play area is free from hazards such as furniture, walls sharp objects, other hard surfaces, etc.
- Set up the product away from water and any potential fire hazards.
- Keep the blower (air pump) and power cord away from areas of water and moisture. If water contacts the blower (air pump), unplug the blower (air pump) power cord. Do not operate until the blower is completely dry.
- Remove the product from the carry bag. Ensure the slide cover coming with the product is stretched well from top to end. Be sure to place the product as close to the power source as possible.
- Stretch the inflation tube and attach it to the end of the blower (air pump). Ensure the inflation tube is securely attached and in good condition. The inflation tube should be straight and untwisted. Reposition the blower (air pump) if necessary.)
- If the product comes with water bags, please follow the undermentioned instruction. Otherwise, overleap this point. Spread out the product, place and fasten the empty water bags on the two sides of the product. Open the stopple and fill water in the water bags until 80% full (about 22 KG/49 LBS), push and close the stopple. Make sure water bags are firmly attached to the product and no water leakage before the product is fully inflated, and never allow children to play on the slide without installing a water bag. (refer to picture A)
- Push ground stakes through blower base holes. You may need to use a hammer for proper placement. Make sure the blower (air pump) power switch is in the OFF position. Ensure the power connections are safely sited and tripping hazard is minimized.
- The blower (air pump) should be securely sited and affixed to the ground before use. Plug the blower (air pump) into an approved ground outlet.

- Ensure the blower(air pump)is free from debris and securely sited to avoid tipping.
- Turn the blower (air pump)power switch to ON. The continual air-flow blower(air pump)must be left ON at all times while the product is being used.(refer to picture B)
- The product should be fully inflated.
- Ground support stakes are used for lawn ground surfaces. Hook and fit each provided ground stake through each loop in the bouncer. To prevent overturn or lift during playing, push stakes firmly into the soil. Make sure the hooked end of the stake is over the loop at all times during use. The stakes should be placed level with or under the ground to reduce tripping hazards. (refer to picture C)
- Please check the age recommendation and user weights(printed on the product). You must not exceed the total weight for the product.
- Put the included play accessories if any for playing into the product.(refer to picture D,E)
- If the product comes with support cushions at the sides, do not stand or sit on the cushions.

Hint: Air leak from the seams is necessary because the product is inflated by constant airflow and this leakage is required to stop the product from becoming over-inflated.

Hint: It is drawn the user's attention to the orientation of inflatable equipment installation to the sun. The sliding surface of the product shall not face the sun as sunshine can glare the children's eyes when they are sliding down along the slide.



## TAKE DOWN

- Make sure all children exit the product.
  - Make sure the product is free from foreign objects.
  - If there is water inside the seams after using the water pool keep the air blower at work for about 30 minutes to dry that out before packing.
  - Turn the blower(air pump) power switch to OFF.
  - Unplug the blower(air pump) power cord.
  - Loosen the EN and detach the inflation tube from the blower. The product should deflate on its own within 5 minutes. Make sure the product is entirely deflated. (refer to picture F) Remove ground support stakes.
  - Fold the product in half from both ends, and then fold it in half 2 more times from both sides, vertically to the first fold. (refer to picture G,H,I)
- Roll it up tightly from the end opposite the inflation tube. (refer to picture J,K)
- Slip the carry bag over the folded product and stakes (plastic balls or water bags ). Zip the bag. (refer to picture L)



## MAINTENANCE

- Checks and maintenance of the main parts of the toys should be carried out at regular intervals, if these checks are not carried out, the toys could overturn or otherwise become a hazard. Whenever practical, the instructions shall also be affixed to the toy.
- The seasonal inspection and maintenance should be conducted for any damage or leakage of the product.
- The product can be wiped clean with a mild detergent. Keep water away from the blower(air pump) at all times.
- Do not store the product when wet. Store the product and the blower indoors in dry conditions when not in use.

## REPAIR


In case of any breakage of product, please patch up through hand sewing. Each type of product is provided with a repair kit which includes six pieces of cloth( two pieces for each color ). Threads and sewing needles are not provided and you should purchase by yourself (3# sewing needle is suggested).

- Turn off the air blower and deflate the product.
- Thread a needle with a spare thread and tie a knot at its end.
- Close up the broken cloth and sew along the gap. Tie a knot after sewing to avoid the loose thread.

In case of cloth breakage(as shown in picture M ). please cover the breakage with a piece of patching cloth of proper size. Then sew up the patching cloth along its sides.

While repairing, you should take notice that the sewing should only occur on the surface layer of the original cloth rather than reaching its underlayer.


- In case of breakage in the seam position (as shown in picture N), the sewing should only occur between the two split cloths rather than reaching the underlayer or any other cloth.
- In case of large-size breakage or internal structural damage, please change the product or have professionals do the repairing. Air leakage is normal in the repaired position and the air pressure of the repaired product may be lower than the original. But it will not affect the normal use of the product.
- Patching in one position more than twice is not suggested.
- Needles should be taken good care of and not be left on the product after sewing.
- It is suggested that persons with sewing techniques should do the repairing work.




## WATER PIPE SETUP INSTRUCTION

### NOTE: ONLY FOR THE BOUNCER WITH WATERSLIDE AND SPRAY FUNCTION.

The different water slide has different quantity of sprinklers, thus, there are serial numbers on each one to match the product. No.1 will match No.1, and No.2 will match No.2. After confirming the position of each sprinkler, please wrap the water pipe along with the hook and loop fastener.



- Attach the water tube provided along the side of the slide using the hook and loop straps (Fig. A2 and A3).
- Connect water supply with a regular garden hose with the provided water tube. The 2-part adaptor of the water tube will fit most garden hoses. Unscrew the 2-part adaptor to find the right fitting for your hose.
- Attach the sprinkler heads to the arch above the slide and water cannon with the hook and loop attachment (Fig A1) as shown in the diagram below.
- Turn on the water faucet to the garden hose. Note: Increase the water pressure gradually until water spraying from the sprinklers reaches the desired power.
- For wet use, fill the pool with at least 20 cm/8 inch of water before playing. Water should be added regularly to maintain the water level in the pool.



**NOTE:** IT IS NORMAL TO HEAR AND FEEL A FAIR AMOUNT OF AIR ESCAPING FROM THE SEAM LINES. IT

IS NORMAL TO SEE SOME WATER SEEPING OUT AROUND THE SEAM LINES OF THE POOL.