




Replacement Parts List

Two Handle Pull Out Laundry Faucet

MODEL	SKU #	FINISH
67655-0001	886323	Chrome



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Sprayhead & Hose	RP3828201		
2	Inverter	RP70543		
3	Inverter	RP70542		
4	Index H	RP1008501		
5	Index C	RP1008601		
6	Screw	RP50013		
7	Handle H	RP1344501		
8	Handle C	RP1344601		
9	Bonnet nut	RP70435	206864739	
10	Washer	RP64124		
11	Cartridge	RP22012	207114089	

Part	Description	Part #	Internet SKU #	Store SKU #
12	Seat & Spring	RP22008	207114089	
13	Gasket	RP80522		
14	Mounting nut	RP56001	203193994	579276
15	Block	RP70421	206116636	
16	O-ring	RP60002		
17	Quick connect Assembly	RP70429		
18	O-ring	RP60089		
19	Weight	RP70441	207093823	
20	Weight clip	RP64204		