

REPAIR SHEET

BRAND

RYOBI

DESCRIPTION


18 Volt Reciprocating Pruning Saw

MODEL NO.

P2503

MFG. NO.

107440003




TECHTRONIC INDUSTRIES POWER EQUIPMENT

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

5-19-21 (Rev:01)


The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.



**P2503****PARTS LIST**

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	538248001	Lock-Out Lever	1
2	537892001	Switch Cover	1
3	697957001	Safety Knob Spring	1
4	697958001	Safety Lever Spring	1
5	538249001	Trigger	1
6	538252001	Clamp Release Hook	1
7	697947001	Hook Spring	1
8	679073001	Spring	1
9	612861005	Saw-Bar Rear Bushing	1
10	314820001	Reciprocate Mechanism Assembly	1
11	679978001	Needle Bearing	1
12	314824001	Counter Mass and Pin Assembly	1
13	614046001	Mass Cage	1
14	205521001	Motor, Switch, and Battery Contact Assembly	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
15	660211038	Screw (M3 x 5 mm, Pan Hd.)	2
16	660206058	Screw (M3.5 x 12 mm, Pan Hd.)	11
17	538251001	Clamp Release Button (Right)	1
18	315448001	Clamp Assembly	1
19	207003001	Housing Assembly (Inc. Key Nos. 25 & 26)	1
20	538250001	Clamp Release Button (Left)	1
21	311444002	Saw-Bar Assembly	1
22	682396001	Blade	1
23	207002001	Battery Foot Assembly (Inc. Key No. 24)	1
24	941107069	Warning Label	1
25	941588916	Logo Label	2
26	941588915	Data Label/Battery Statement	1
	Not Shown:		
	998000534	Operator's Manual	

**WIRING DIAGRAM**