













READ AND SAVE THESE INSTRUCTIONS FOR FUTURE USE

ASSEMBLY INSTRUCTION













PACKING DETAILS : TOTAL 2 BOX

BOX 1/2:



PARTNO.	PARTS	QTY
1		x1
6		x1
10		x8
15		x1
16		x2
17		x1
18		x1
23		x2
27		x1
28		x1
29		x1
30		x1

BOX 2/2:

PARTNO.	PARTS	QTY
2		x1
3		x1
4		x2
5		x2
7		x1
8		x1
9		x1
11		x1
12		x1
13		x1
14		x1
19		x1
20		x1
21		x1
22		x1
24		x2
25		x1
26		x1




PACKING DETAILS : TOTAL 2 BOX

BOX 2/2:




PARTNO.	PARTS	QTY
A		x54
B		x44
C		x44
D	 Ø4×20mm	x4
E	 Ø4×40mm	x2
F	 Ø3.8×35mm	x5
G	 Ø4×30mm	x20
H		x8
I	 Ø3.5×12mm	x12
J	 Ø4.7×12.5mm	x4
K	 Ø3.5×12mm	x4
L		x2
M		x2
N		x2
O		x4
P		x22
Q		x2
R		x20







PARTNO.	PARTS	QTY
S	 Ø3×16mm	x20
T		x5
U	 M4×30mm	x4
V	 M4×18mm	x1
W	 Ø4×14mm	x4
X		x8
Y	 Ø4×14mm	x48
Z		x1
Aa		x1
Bb		x1
Cc		x1
Dd		x1
Ee		x1







01






02





























8









13





x2

14








x8




15





16



































x2









































T	X1	U	X1	X	X2	Y	X4
							














x2




T	X1	U	X1	X	X2	Y	X4
							












x2











US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it