

Acacia Wood Furniture Care Guide

1. Handle with Care – Avoid Impact

Although acacia wood is dense and durable, it can still crack or chip under strong impact. Always lift and move furniture gently, and avoid dropping boxes or hitting against hard surfaces.

2. Apply a Clear Coat Before Use

The wood comes with basic protection, but applying an additional layer of outdoor-grade clear varnish or teak oil before use will enhance water, stain, and UV resistance.

3. Cover or Store When Not in Use

Prolonged exposure to sun, rain, and wind will accelerate aging and fading. When not in use, cover with a protective cover or move into a shed, garage, or other sheltered area.

4. Regular Cleaning & Maintenance

Wipe the surface monthly with a soft cloth and mild detergent to remove dust and stains. Avoid harsh acids, alkalis, or abrasive cleaners.

5. Avoid Standing Water

After rain, wipe off any standing water on tabletops or seats to prevent moisture from seeping in and causing swelling or mold.

6. Keep Away from Heat & Sharp Objects

Do not place hot pots, grills, or sharp objects directly on the wood surface. Use placemats, coasters, or heat pads for protection.

7. Deep Maintenance Every Six Months

Apply teak oil or outdoor furniture oil every six months to restore luster and extend the life of the wood.

8. Fully Dry Before Long-Term Storage

If storing for the winter or long term, make sure the furniture is completely dry before covering or putting away to prevent mold or warping.