



# BLACK CUBE™

BY FRIELING

## USE & CARE

---


### Before the first use:

Clean with dishwashing detergent and hot tap water or place in dishwasher.

---

### Use:

For best cooking results, use low or medium heat when cooking. Center the cookware on the burner, using a burner no larger than the bottom of the cookware. After use, allow cookware to cool naturally on its own.



### Preheating:

Most recipes recommend preheating a pan before cooking. To preheat, place the pan over medium heat. After 1-2 minutes, sprinkle with a few drops of water. If the water sizzles and forms tiny drops, the pan is ready for cooking. If the water evaporates, allow to cool slightly before cooking.

---

**WARNING:** Excessive preheating of empty cookware may cause damage.

---

### Oven use:

BLACK CUBE™ Cookware is oven safe up to **500° F.**



**WARNING:** To prevent burns always use pot holders or oven mitts.

---

### Cooking Oil / Non-Stick Sprays:

#### **NEVER USE AEROSOL NONSTICK SPRAYS**

The propellant in such sprays will harm the nonstick coating of any brand nonstick cookware. Instead, fill a non-aerosol pump spray bottle (oil mister) with your choice of oil. Always use the proper heat setting for the type oil you are using; do not exceed its smoke point.





# BLACK CUBE™

BY FRIELING

## Cleaning and care:

BLACK CUBE™ Cookware can be washed in a dishwasher. When washing by hand, do not use abrasives, scouring powders or oven cleaners as these will mar the finish. To clean the outside, use cleaners expressly recommended for stainless steel. Keeping your cookware clean and looking nice will preserve its cooking efficiency.

**Tip:** To prevent water spots after washing, Frieling recommends that you rinse with hot water and wipe dry immediately.

## CAUTION:

- To avoid the risk of fire, and to keep your BLACK CUBE™ cookware in its best condition, never leave anything cooking unattended.
- Never allow anything to boil dry in the cookware.
- Excess temperature can cause discoloration. If this occurs, **DO NOT REMOVE THE COOKWARE RIGHT AWAY.** Instead, turn off the heat and allow it to cool naturally.

### Limited Lifetime Warranty:

The manufacturer warrants to the original owner of the cookware that this product is free of manufacturing defects (in materials and workmanship) for the lifetime of the product.

This warranty does not apply if the Use and Care instructions published in our literature have not been followed. This warranty does not cover damage or destruction caused by misuse, abuse, accident, overheating, alterations or commercial use. This warranty does not cover stains, discoloration, exterior scratch marks, dents and natural loss of its nonstick properties over time. Incidental or consequential damages are expressly excluded by this warranty.

Defective products may be returned by the original purchaser or any subsequent owner within the warranty period, postage pre-paid to Frieling USA, 398 York Southern Road, Fort Mill, SC 29715.

Any item found to be defective will be repaired or replaced, at manufacturer's discretion. Should the defective item no longer be available, for whatever reason, an item of similar function and value will be substituted. This warranty is expressly not a money-back guarantee.

If your BLACK CUBE™ cookware is found to be defective in materials or workmanship, please contact Frieling USA, Inc.