



ITEM # SWHCB Sheesham Rosewood Live Edge Wood Bench

Assembly Instructions - Max Weight Capacity 400 lbs

Components:



1 Piece Bench Top




2 Pieces Bench Legs




12 Long Bolts





1 Hex Wrench




1) Place Bench Top on smooth surface.



2) Attach Bench Leg to Bench Top using 6 Long Bolts.



3) Attach remaining Bench Leg using 6 Long Bolts.



4) Tighten all bolts. Place bench upright.

If you experience a problem, have questions or need parts for this product, visit our website
call Customer Service at **1-636-532-9888, Monday-Friday, 8 AM - 4 PM Central Time**