

Owner's Manual
Item # CRD111S-GD



Festive Golden Christmas Tree with Warm White LED Lights



**Have Questions or Issues? Need help with assembly?
Contact us and we will resolve them within 12 hours.**

Support Hours: M-F 7:30–5:00 (U.S. Pacific Time)



Call:
877-460-4511



Email:
info@alpine4u.com

CONTENTS

Contents	1
What's Included	2
Features & Specifications	3
Assembling & Using Your Product	4
Warranty	7
Notes	8

WHAT'S INCLUDED



LED Christmas Tree

1x



Extension Pole

1x



Base Stand

1x



Main Ground Stake

1x




Support Ground Stakes

4x

FEATURES

- 380 Warm white LED lights. 38 twinkling LED lights

- Foldable design for compact storage



- Sturdy metal stand. Includes ground stakes for added stability on soil


SPECIFICATIONS

Power Requirements..... Standard Household 120V
Dimensions 25"L x 25"W x 61"H

ASSEMBLING & USING YOUR PRODUCT

Unpack all components carefully. Please ensure all parts have been removed from the packaging.


1. Place the base stand on a smooth & level surface. Attach the Extension Pole with the securing twist knob at the bottom. Twist the knob clockwise to secure the pole to the base.




2. Insert the bottom end of the LED Christmas tree into the top part of the extension pole.




3. Carefully cut all of the zip-ties around the tree to free up all the branches and power adaptor. Begin spreading out the large branches by carefully bending them down. For the smaller LED branches, spread them out evenly for a blooming effect.



4. For outdoor use on soil, attach the included Main Ground Stake to the bottom of the Base Stand. Insert the stake into the ground until the Base stand touches the ground



5. For additional support, insert the four Support Ground stakes through the holes in the corners of the Base Stand and into the ground.



6. Congratulations, your tree is now complete. Plug the power adaptor into a standard wall socket and enjoy the wonderful twinkling lights.



LIMITED WARRANTY INFORMATION

Thank you for choosing an Alpine product! We aim to please with our wide range of products including Fountains, Birdbaths, Statuary, Pond Supplies & More. All of our products are constructed from the highest quality materials. In the event that we have not achieved our usual standard of excellence, we will repair or replace, at our discretion, within the warranty period. A valid proof of purchase, with the purchase date clearly indicated, must be provided. Photos of defective merchandise will also be required to help distinguish the actual cause of the defect. Please read below for a detailed description of warranty coverage.

- **Water Damage**

Alpine products are not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within a product may cause damage, is considered negligence, and will not be covered under this warranty. The use of "hard water," and/or caustic cleaners, can affect the painted or other finishes. Failure to keep the unit clean, and use of such additives/cleaners, will also void the warranty. Please note: for fountains, it is normal for some splashing to occur and protecting the immediate surfaces is not the responsibility of Alpine Corporation.

- **Paint & Color (Retention and/or Loss)**

The use of water will cause natural erosion to the color. This area can be touched up using standard paint. The paint is designed to protect the entire finish against breakdown of color. As with any product, all finishes with time will gradually fade and discolor. The warranty will only cover against severe or complete fading, within the first year from date of purchase, with the above exclusion.

- **Procedure/Service**

Should a warranty/claim be needed, you should contact the retailer from whom you purchased the product. If that is not an option, you can contact Alpine Corporation at www.alpine4u.com. When contacting Alpine Corporation, you must be prepared to show proof of purchase, provide photographs and any other information needed to validate your claim. This may be necessary to distinguish between a partial or complete replacement of a defective product. The warranty does not cover any items with multiple parts; the warranty will ONLY cover the individual component of the unit/item that may be defective. Replacement parts can be made available to a consumer through the original selling party, or an approved parts retailer. If this is not an option, contact our customer service department. **Item is covered under one year limited warranty from the date of purchase. When requesting replacement parts due to a warranty claim after 30 days of purchase, credit card information will be requested for shipping charges.**

- **Not Covered Under Warranty**

The limited warranty will NOT cover cases of damages due to:

1. Damages caused in Transit
2. Inadequate care and/or neglect
3. Environmental and/or natural elements
4. Immersion in water, unless specified
5. Improper Installation/Storage and/or Maintenance

This warranty is void if the product has been damaged by accident, misuse, negligence, improper installation and/or modifications have occurred. This includes any and/or all defects arising out of freezing water damage, hard water damage, failure to keep the unit clean and free of harmful additives such as bleach, chlorine, etc.... which affects the paint and/or parts. This warranty also does not cover any additional charges or installation, removal, disposal and/or shipping costs or consequential damage associated with any warranty claim

NOTES

Purchased your product online?

We would really appreciate it if you can share your experience with others by reviewing our product on the website from which you purchased.

