

Instruction Manual and Parts List

Item No. 344, Plastic Laminate Scoring Cutter

Usage Instructions:

1. Hold a straight edge firmly on the decorative surface of the laminate sheet, along the line to be cut.
2. Draw the Cutter firmly along the straight edge, scoring completely through the decorative face. The deeper the scoring, the easier it is to break the sheet neatly. This is especially important when making long or narrow cuts.
3. To break the laminate sheet, simply press down firmly on the straight edge (along the scored line), grasp the outer edge of the sheet, and pull upwards.

Note: The No. 344 Plastic Laminate Scoring Cutter is also excellent for scoring/cutting cement based tile backer board and for degROUTING work.

Parts List:

1. Item No. 344-B is the replaceable blade for the cutter.
2. Access the blade by removing the two screws on the side of the cutter.
3. Replace blade and reattach cover.

No. 344
Plastic Laminate Scoring Cutter



No. 344-B
Replacement Blade for No. 344



Beno J. Gundlach Company