

GRAVITY SERIES®

DIGITAL CHARCOAL GRILLS + SMOKERS

LET GRAVITY DO THE WORK.



1 LOAD

Fill GravityFed charcoal hopper with lump charcoal or briquettes.

2 LIGHT

Use paper or fire starter to ignite.

3 SET

Set the temperature on the digital control panel or a smart device.