

### 21in Recycler®/Rear Bagging Lawn Mower

Model No. 21332—Serial No. 400000000 and Up Model No. 21352—Serial No. 400000000 and Up

**Operator's Manual** 

## Introduction

This rotary-blade, walk-behind lawn mower is intended to be used by residential homeowners. It is designed primarily for cutting grass on well-maintained lawns on residential properties. Using this product for purposes other than its intended use could prove dangerous to you and bystanders.

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

Visit www.Toro.com for more information, including safety tips, training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. Figure 1 identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.

*Important:* With your mobile device, you can scan the QR code on the serial number decal (if equipped) to access warranty, parts, and other product information.





1. Model and serial number location

Model No	
Serial No	

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol (Figure 2), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



g000502


This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order or the engine is constructed, equipped, and maintained for the prevention of fire.

The enclosed engine owner's manual is supplied for information regarding the US Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance, and warranty. Replacements may be ordered through the engine manufacturer.

**Gross or Net Torque:** The gross or net torque of this engine was laboratory rated by the engine manufacturer in accordance with the Society of Automotive Engineers (SAE) J1940 or J2723. As configured to meet safety, emission, and operating requirements, the actual engine torque on this class of mower will be significantly lower. Please refer to the engine manufacturer's information included with the machine.

© 2020—The Toro® Company 8111 Lyndale Avenue South Bloomington, MN 55420





#### A WARNING

#### CALIFORNIA

Proposition 65 Warning The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Use of this product may cause exposure to chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

## Contents

Introduction	
Safety	
General Safety	3
Safety and Instructional Decals	4
Setup	5
1 Installing the Handle	5
2 Installing the Recoil-Starter Rope in the	
Rope Guide	6
3 Adding Oil to the Engine	
4 Assembling the Grass Bag	
Product Overview	
Specifications	9
Attachments/Accessories	
Operation	
Before Operation	
Before Operation Safety	
Filling the Fuel Tank	10
Checking the Engine-Oil Level	.11
Adjusting the Cutting Height	12
During Operation	12
During Operation Safety	12
Starting the Engine	13
Using the Self-Propel Drive	14
Shutting Off the Engine	14
Recycling the Clippings	
Bagging the Clippings	
Operating Tips	
After Operation	
After Operation Safety	
Cleaning under the Machine	
Folding the Handle	
Maintenance	18
Recommended Maintenance Schedule(s)	
Maintenance Safety	
Preparing for Maintenance	18
Servicing the Air Filter	19
Changing the Engine Oil	19
Replacing the Blade	
Storage	
Storage Safety	21
Preparing the Machine for Storage	21
Removing the Machine from Storage	21

# Safety

This machine has been designed in accordance with ANSI B71.1-2017.

### **General Safety**

This product is capable of amputating hands and feet and of throwing objects. Always follow all safety instructions to avoid serious personal injury or death.

- Read, understand, and follow the instructions and warnings in this *Operator's Manual* and on the machine and attachments before starting the engine.
- Do not put your hands or feet near moving parts or under the machine. Keep clear of any discharge opening.
- Do not operate the machine without all guards and other safety protective devices in place and functioning properly on the machine.
- Keep bystanders and children out of the operating area. Do not allow children to operate the machine. Allow only people who are responsible, trained, familiar with the instructions, and physically capable to operate the machine.
- Stop the machine, shut off the engine, and wait for all moving parts to stop before servicing, fueling, or unclogging the machine.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol  $\clubsuit$ , which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

### **Safety and Instructional Decals**




Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



Manufacturer's Mark

1. This mark indicates that the blade is identified as a part from the original machine manufacturer.





117-4143

- 1. Warning—read the Operator's Manual.
- 2. Thrown object hazard-keep bystanders away.
- 3. Cutting/dismemberment hazard of hand or foot, mower blade—disconnect the spark-plug wire and read the *Operator's Manual* before performing maintenance.
- 4. Cutting/dismemberment hazard of hand or foot, mower blade—stay away from moving parts; keep all guards and shields in place.
- 5. Cutting/dismemberment hazard of hand or foot, mower blade—do not operate up and down slopes; only operate across slopes; shut off the engine and wait for all moving parts to stop before leaving the machine; pick up debris before mowing; look behind and down when moving in reverse.

 WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov. For more information, please visit www.ttcoCAProp65.com CALIFORNIA SPARK ARRESTER WARNING Operation of this equipment may create sparks that can start fires around dry regetation. A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

133-8062

decal133-8062

# Setup

*Important:* Remove and discard the protective plastic sheet that covers the engine and any other plastic or wrapping on the machine.



### Installing the Handle

**No Parts Required** 

#### Procedure

#### A WARNING

Folding or unfolding the handle improperly can damage the cables, causing an unsafe operating condition.

- Do not damage the cables when folding or unfolding the handle.
- If a cable is damaged, contact an Authorized Service Dealer.
- 1. Remove the handle knobs and corresponding bolts from the machine housing (A of Figure 3).
- 2. Position the upper handle on the lower handles and then unfold the handle (B of Figure 3).
- 3. Install the handle knobs with the corresponding bolts and tighten them firmly by hand (C of Figure 3).




Figure 3

2

### Installing the Recoil-Starter Rope in the Rope Guide

**No Parts Required** 

#### Procedure

*Important:* To start the engine safely and easily whenever you use the machine, install the recoil-starter rope in the rope guide.





Figure 4

# **3** Adding Oil to the Engine

**No Parts Required** 

#### Procedure


*Important:* If the oil level in the engine is too low or too high and you run the engine, you may damage the engine.



# **4** Assembling the Grass Bag


#### No Parts Required

#### Procedure





# **Product Overview**



#### **Attachments/Accessories**

A selection of Toro approved attachments and accessories is available for use with the machine to enhance and expand its capabilities. Contact your Authorized Service Dealer or authorized Toro distributor or go to www.Toro.com for a list of all approved attachments and accessories.

To ensure optimum performance and continued safety certification of the machine, use only genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous, and such use could void the product warranty.

- 1. Self-propel-drive bar (self-propel model only)
- 7. Air filter
- 8. Spark

9.

- 2. Blade-control bar
- Adjustment for the self-propel drive (self-propel model only)

Spark plug

Cutting-height lever (2)

- 4. Rear deflector
- 5. Handle knob (2)
- 6. Fuel-tank cap
- 10. Oil fill/dipstick
- 11. Grass bag
- 12. Recoil-start handle

### **Specifications**

Model	Weight	Length	Width	Height
21332	30 kg			
21332	(67 lb)	142 cm	56 cm	102 cm
21352	34 kg	(56 inches)	(22 inches)	(40 inches)
	(76 lb)			

# Operation

**Note:** Determine the left and right sides of the machine from the normal operating position.

## **Before Operation**

### **Before Operation Safety**

### **General Safety**

- Always shut off the machine, wait for all moving parts to stop, and allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Become familiar with the safe operation of the ٠ equipment, operator controls, and safety signs.
- Check that all guards and safety devices, such as deflectors and/or grass catcher, are in place and functioning properly.
- Always inspect the machine to ensure that the ٠ blades and blade bolts are not worn or damaged.
- Inspect the area where you will use the machine, and remove all objects that could interfere with the operation of the machine or that the machine could throw.
- Contact with the moving blade will cause serious ٠ injury. Do not put your fingers under the housing.

### **Fuel Safety**

- Fuel is extremely flammable and highly explosive. A fire or explosion from fuel can burn you and others and can damage property.
  - To prevent a static charge from igniting the fuel, place the container and/or machine directly on the ground before filling, not in a vehicle or on an object.
  - Fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any fuel that spills.
  - Do not handle fuel when smoking or around an open flame or sparks.
  - Do not remove the fuel cap or add fuel to the tank while the engine is running or hot.
  - If you spill fuel, do not attempt to start the engine. Avoid creating a source of ignition until the fuel vapors have dissipated.
  - Store fuel in an approved container and keep it out of the reach of children.
- Fuel is harmful or fatal if swallowed. Long-term exposure to vapors can cause serious injury and illness.

- Avoid prolonged breathing of vapors.
- Keep your hands and face away from the nozzle and the fuel-tank opening.
- Keep fuel away from your eyes and skin.

### Filling the Fuel Tank

Туре	Unleaded gasoline
Minimum octane rating	87 (US) or 91 (research octane; outside the US)
Ethanol	No more than 10% by volume
Methanol	None
MTBE (methyl tertiary butyl ether)	Less than 15% by volume
Oil	Do not add to the fuel

Use only clean, fresh (no more than 30 days old), fuel from a reputable source.

#### *Important:* To reduce starting problems, add fuel stabilizer/conditioner to fresh fuel as directed by the fuel-stabilizer/conditioner manufacturer.

Refer to your engine owner's manual for additional information.

Fill the fuel tank as shown in Figure 8.




Figure 8


a230458

10

### **Checking the Engine-Oil Level**

Service Interval: Before each use or daily

*Important:* If the oil level in the crankcase is too low or too high and you run the engine, you may damage the engine.



## **Adjusting the Cutting Height**

#### A WARNING

Adjusting the cutting-height levers could bring your hands into contact with a moving blade and result in serious injury.


- Shut off the engine and wait for all moving parts to stop before adjusting the cutting height.
- Do not put your fingers under the housing when adjusting the cutting height.

#### **A** CAUTION

If the engine has been running, the muffler will be hot and can burn you.

Keep away from the hot muffler.

Adjust the cutting height as desired. Set all wheels to the same cutting height (Figure 10).





### **During Operation**

### **During Operation Safety**

### **General Safety**

• Wear appropriate clothing, including eye protection; long pants; substantial, slip-resistant footwear; and hearing protection. Tie back long

hair and do not wear loose clothing or loose jewelry.

- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Do not operate the machine while ill, tired, or under the influence of alcohol or drugs.

- The blade is sharp; contacting the blade can result in serious personal injury. Shut off the engine and wait for all moving parts to stop before leaving the operating position.
- When you release the blade-control bar, the engine should shut off and the blade should stop within 3 seconds. If not, stop using your machine immediately and contact an Authorized Service Dealer.
- Keep bystanders out of the operating area. Keep small children out of the operating area and under the watchful care of a responsible adult who is not operating the machine. Stop the machine if anyone enters the area.
- Always look down and behind you before moving the machine in reverse.
- Operate the machine only in good visibility and appropriate weather conditions. Do not operate the machine when there is the risk of lightning.
- Wet grass or leaves can cause serious injury if you slip and contact the blade. Avoid mowing in wet conditions.
- Use extreme care when approaching blind corners, shrubs, trees, or other objects that may block your view.
- Do not direct the discharge material toward anyone. Avoid discharging material against a wall or obstruction; material may ricochet toward you. Stop the blade(s) when crossing gravel surfaces.

- Watch for holes, ruts, bumps, rocks, or other hidden objects. Uneven terrain could cause you to lose your balance or footing.
- If the machine strikes an object or starts to vibrate, immediately shut off the engine, wait for all moving parts to stop, and disconnect the wire from the spark plug before examining the machine for damage. Make all necessary repairs before resuming operation.
- Before leaving the operating position, shut off the engine and wait for all moving parts to stop.
- If the engine has been running, it will be hot and can severely burn you. Keep away from the hot engine.
- Operate the engine only in well-ventilated areas. Exhaust gases contain carbon monoxide, which is an odorless, deadly poison.
- Check the grass catcher components and the discharge chute frequently for any wear or deterioration and replace them with genuine Toro parts when necessary.

#### **Slope Safety**

- Mow across the face of slopes; never up and down. Use extreme caution when changing direction on slopes.
- Do not mow on excessively steep slopes. Poor footing could cause a slip-and-fall accident.
- Mow with caution near drop-offs, ditches, or embankments.

### **Starting the Engine**

- 1. Hold the blade-control bar against the handle (A of Figure 11).
- 2. Pull the recoil-start handle (B of Figure 11).

**Note:** When you pull the recoil-start handle, pull it lightly until you feel resistance, then pull it sharply. Allow the rope to return to the handle slowly.

**Note:** If the machine does not start after several attempts, contact an Authorized Service Dealer.





Figure 11

### **Using the Self-Propel Drive**

### Self-Propel Model Only

• To engage the self-propel drive, pull the self-propel-drive bar to the handle and hold it (Figure 12).



**Note:** The maximum self-propel-drive speed is fixed. To reduce the speed, increase the space between the self-propel-drive bar and the handle.

• To disengage the self-propel-drive, release the self-propel drive bar.

1. Self-propel-drive bar

### Shutting Off the Engine

Service Interval: Before each use or daily—Ensure that the engine shuts off within 3 seconds after releasing the blade-control bar.

a240765

To shut off the engine, release the blade-control bar.

*Important:* When you release the blade-control bar, the engine should shut off and the blade should stop within 3 seconds. If they do not, stop using your machine immediately and contact an Authorized Service Dealer.

### **Recycling the Clippings**

Your machine comes from the factory ready to recycle the grass and leaf clippings back into the lawn.

If the grass bag is on the machine, remove it before recycling the clippings. Refer to Removing the Grass Bag (page 15).

### **Bagging the Clippings**

Use the grass bag when you want to collect grass and leaf clippings from the lawn.


#### A WARNING

A worn grass bag could allow small stones and other similar debris to be thrown toward you or bystanders, resulting in serious personal injury or death.

Check the grass bag frequently. If it is damaged, install a new Toro replacement bag.

### Installing the Grass Bag

- 1. Lift up the rear deflector (A of Figure 13).
- 2. Insert the rod ends of the grass bag into the notches in the handle brackets (B of Figure 13).
- 3. Allow the rear deflector to rest on the bag.





g240796

### **Removing the Grass Bag**

- 1. Lift up the rear deflector (A of Figure 13).
- 2. Lift the grass-bag handle out from the notches on the handle brackets and remove the bag from the machine.
- 3. Close the rear deflector.

## **Operating Tips**

### **General Mowing Tips**

- Inspect the area where you will use the machine and remove all objects that the machine could throw.
- Avoid striking solid objects with the blade. Never deliberately mow over any object.
- If the machine strikes an object or starts to vibrate, immediately shut off the engine, wait for all moving

parts to stop, disconnect the wire from the spark plug, and examine the machine for damage.

• For best performance, install a new Toro blade before the cutting season begins or when necessary.

### **Cutting Grass**

• Cut only about a third of the grass blade at a time. Do not cut below 51 mm (2 inches) unless the grass is sparse or it is late fall when grass growth begins to slow down.

- When cutting grass over 15 cm (6 inches) tall, mow at the highest cutting height setting and walk slower; then mow again at a lower setting for the best lawn appearance. If the grass is too long, the machine may plug and cause the engine to stall.
- Wet grass and leaves tend to clump on the yard and can cause the machine to plug or the engine to stall. Avoid mowing in wet conditions.
- Be aware of a potential fire hazard in very dry conditions, follow all local fire warnings, and keep the machine free of dry grass and leaf debris.
- Alternate the mowing direction. This helps disperse the clippings over the lawn for even fertilization.
- If the finished lawn appearance is unsatisfactory, try 1 or more of the following:
  - Replace the blade or have it sharpened.
  - Walk at a slower pace while mowing.
  - Raise the cutting height on your machine.
  - Cut the grass more frequently.
  - Overlap cutting swaths instead of cutting a full swath with each pass.

#### **Cutting Leaves**

- After cutting the lawn, ensure that half of the lawn shows through the cut leaf cover. You may need to make more than a single pass over the leaves.
- If there are more than 13 cm (5 inches) of leaves on the lawn, mow at a higher cutting height and then again at the desired cutting height.
- Slow down your mowing speed if the machine does not cut the leaves finely enough.

## After Operation

### **After Operation Safety**

#### **General Safety**

- Always shut off the machine, wait for all moving parts to stop, and allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Clean grass and debris from the machine to help prevent fires. Clean up oil or fuel spills.
- Never store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or on other appliances.

### **Hauling Safety**

- Use care when loading or unloading the machine.
- Secure the machine from rolling.

## **Cleaning under the Machine**

#### Service Interval: After each use

For best results, clean under the machine soon after you have completed mowing.

- 1. Lower the machine to its lowest cutting-height setting.
- 2. Move the machine onto a paved level surface.
- 3. With the engine running and the blade engaged, spray a stream of water in front of the **right**, rear wheel (Figure 14).

**Note:** The water will splash into the path of the blade, cleaning out the clippings.



Figure 14


- 4. When no more clippings come out, stop the water and move the machine to a dry area.
- 5. Run the engine for a few minutes to dry the underside of the machine.

### **Folding the Handle**

#### A WARNING

Folding or unfolding the handle improperly can damage the cables, causing an unsafe operating condition.

- Do not damage the cables when folding or unfolding the handle.
- If a cable is damaged, contact an Authorized Service Dealer.
- 1. Remove the ignition key (if equipped).
- 2. Loosen the handle knobs until you can move the handle freely (Figure 15).



- 1. Handle knob (2)
- 3. Move the handle forward as shown in Figure 15.

# Maintenance

### **Recommended Maintenance Schedule(s)**

Maintenance Service Interval	Maintenance Procedure
Before each use or daily	<ul> <li>Check the engine-oil level and add oil as needed.</li> <li>Ensure that the engine shuts off within 3 seconds after releasing the blade-control bar.</li> </ul>
After each use	<ul> <li>Clean grass clippings and dirt from under the machine.</li> </ul>
Every 25 hours	Service the air filter; service it more frequently in dusty operating conditions.
Yearly	<ul> <li>Replace the air filter.</li> <li>Replace the blade or have it sharpened (more frequently if the edge dulls quickly).</li> <li>Clean the engine by removing dirt and debris from its top and sides; clean it more frequently in dusty operating conditions.</li> </ul>
Yearly or before storage	<ul> <li>Empty the fuel tank before repairs as directed and before yearly storage.</li> </ul>


Important: Refer to your engine owner's manual for additional maintenance procedures.

### **Maintenance Safety**

- Always shut off the machine, wait for all moving parts to stop, and allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Disconnect the spark-plug wire from the spark plug before performing any maintenance procedure.
- Wear gloves and eye protection when servicing the machine.
- The blade is sharp; contacting the blade can result in serious personal injury. Wear gloves when servicing the blade. Do not repair or alter the blade(s).
- Never tamper with safety devices. Check their proper operation regularly.
- Tipping the machine may cause the fuel to leak. Fuel is flammable and explosive, and can cause personal injury. Run the engine dry or remove the fuel with a hand pump; never siphon the fuel.
- To ensure optimum performance of the machine, use only genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous, and such use could void the product warranty.

### **Preparing for Maintenance**

- 1. Shut off the engine, remove the ignition key (if equipped), and wait for all moving parts to stop.
- 2. Disconnect the spark-plug wire from the spark plug (Figure 16).




- 1. Spark-plug wire
- 3. After performing the maintenance procedure(s), connect the spark-plug wire to the spark plug.

### Servicing the Air Filter

Service Interval: Every 25 hours/Yearly (whichever comes first)—Service the air filter; service it more frequently in dusty operating conditions.

1. Lift the tab to open the air-filter cover (Figure 17).



1. Tab

- 2. Replace the air filter.
- 3. Close the air-filter cover.

## **Changing the Engine Oil**

Changing the engine oil is not required, but if you desire to change the oil, use the following procedure.

**Note:** Run the engine a few minutes before changing the oil to warm it. Warm oil flows better and carries more contaminants.

#### **Engine Oil Specifications**

Engine oil capacity	0.44 L (15 fl oz)*
Oil viscosity	SAE 30 or SAE 10W-30 detergent oil
API service classification	SJ or higher

\*There is residual oil in the crankcase after you drain the oil. Do not pour the entire capacity of oil into the crankcase. Fill the crankcase with oil as directed in the following steps.

- 1. Move the machine to a level surface.
- 2. Refer to Preparing for Maintenance (page 18).
- 3. Remove the dipstick by rotating the cap counterclockwise and pulling it out (Figure 18).





Figure 18

4. Tip the machine onto its side (so that the air filter is up) to drain the used oil from the oil-fill tube (Figure 19).



- 5. After draining the used oil, return the machine to the operating position.
- 6. Carefully pour about 3/4 of the engine capacity of oil into the oil-fill tube.
- 7. Wait 3 minutes for the oil to settle in the engine.
- 8. Wipe the dipstick clean with a clean cloth.
- 9. Insert the dipstick into the oil-fill tube, screw it in, then remove the dipstick.
- 10. Read the oil level on the dipstick (Figure 18).
  - If the oil level on the dipstick is too low, carefully pour a small amount of oil into the oil-fill tube, wait 3 minutes, and repeat steps

8 through 10 until the oil level on the dipstick is correct.

• If the oil level on the dipstick is too high, drain the excess oil until the oil level on the dipstick is correct.

*Important:* If the oil level in the engine is too low or too high and you run the engine, you may damage the engine.

- 11. Install the dipstick into the oil-fill tube securely.
- 12. Recycle the used oil properly.

### **Replacing the Blade**

Service Interval: Yearly

*Important:* You will need a torque wrench to install the blade properly. If you do not have a torque wrench or are uncomfortable performing this procedure, contact an Authorized Service Dealer.


Examine the blade whenever you run out of fuel. If the blade is damaged or cracked, replace it immediately. If the blade edge is dull or nicked, have it sharpened and balanced, or replace it.

#### A WARNING


The blade is sharp; contacting the blade can result in serious personal injury.

#### Wear gloves when servicing the blade.

- 1. Refer to Preparing for Maintenance (page 18).
- 2. Tip the machine onto its side with the air filter up.
- 3. Use a block of wood to hold the blade steady (Figure 20).



- 4. Remove the blade, saving all mounting hardware (Figure 20).
- 5. Install the new blade and all mounting hardware (Figure 21).



*Important:* Position the curved ends of the blade to point toward the machine housing.

6. Use a torque wrench to tighten the blade bolt to 82 N·m (60 ft-lb).

# Storage

Store the machine in a cool, clean, dry place.

## **Storage Safety**

Always shut off the machine, wait for all moving parts to stop, and allow the machine to cool before adjusting, servicing, cleaning, or storing it.

# Preparing the Machine for Storage

- On the last refueling of the year, add fuel stabilizer (such as Toro Premium Fuel Treatment) to the fuel as directed on the label.
- 2. Dispose of any unused fuel properly. Recycle it according to local codes or use it in your automobile.

*Important:* Old fuel in the fuel tank is the leading cause of hard starting. Do not store the fuel without fuel stabilizer more than 30 days, and do not store stabilized fuel beyond the duration recommended by the fuel-stabilizer manufacturer.

- 3. Run the machine until the engine shuts off from running out of fuel.
- 4. Start the engine again and allow it to run until it shuts off. When you can no longer start the engine, it is sufficiently dry.
- 5. Disconnect the wire from the spark plug and connect the wire to the retaining post (if equipped).
- 6. Remove the spark plug, add 30 ml (1 fl oz) of engine oil through the spark-plug hole, and pull the starter rope slowly several times to distribute oil throughout the cylinder to prevent cylinder corrosion during the off-season.
- 7. Loosely install the spark plug.
- 8. Tighten all nuts, bolts, and screws.

# Removing the Machine from Storage

- 1. Check and tighten all fasteners.
- 2. Remove the spark plug and spin the engine rapidly by pulling the recoil-start handle to blow the excess oil from the cylinder.
- 3. Install the spark plug and tighten it with a torque wrench to 20 N⋅m (15 ft-lb).

- 4. Perform any maintenance procedures; refer to Maintenance (page 18).
- 5. Check the engine-oil level; refer to Checking the Engine-Oil Level (page 11).
- 6. Fill the fuel tank with fresh fuel; refer to Filling the Fuel Tank (page 10).
- 7. Connect the wire to the spark plug.

## Notes:

#### **California Proposition 65 Warning Information**

#### What is this warning?

You may see a product for sale that has a warning label like the following:



#### What is Prop 65?

Prop 65 applies to any company operating in California, selling products in California, or manufacturing products that may be sold in or brought into California. It mandates that the Governor of California maintain and publish a list of chemicals known to cause cancer, birth defects, and/or other reproductive harm. The list, which is updated annually, includes hundreds of chemicals found in many everyday items. The purpose of Prop 65 is to inform the public about exposure to these chemicals.

Prop 65 does not ban the sale of products containing these chemicals but instead requires warnings on any product, product packaging, or literature with the product. Moreover, a Prop 65 warning does not mean that a product is in violation of any product safety standards or requirements. In fact, the California government has clarified that a Prop 65 warning "is not the same as a regulatory decision that a product is 'safe' or 'unsafe.'" Many of these chemicals have been used in everyday products for years without documented harm. For more information, go to https://oag.ca.gov/prop65/faqs-view-all.

A Prop 65 warning means that a company has either (1) evaluated the exposure and has concluded that it exceeds the "no significant risk level"; or (2) has chosen to provide a warning based on its understanding about the presence of a listed chemical without attempting to evaluate the exposure.

#### Does this law apply everywhere?

Prop 65 warnings are required under California law only. These warnings are seen throughout California in a wide range of settings, including but not limited to restaurants, grocery stores, hotels, schools, and hospitals, and on a wide variety of products. Additionally, some online and mail order retailers provide Prop 65 warnings on their websites or in catalogs.

#### How do the California warnings compare to federal limits?

Prop 65 standards are often more stringent than federal and international standards. There are various substances that require a Prop 65 warning at levels that are far lower than federal action limits. For example, the Prop 65 standard for warnings for lead is 0.5 µg/day, which is well below the federal and international standards.

#### Why don't all similar products carry the warning?

- Products sold in California require Prop 65 labelling while similar products sold elsewhere do not.
- A company involved in a Prop 65 lawsuit reaching a settlement may be required to use Prop 65 warnings for its products, but other companies
  making similar products may have no such requirement.
- The enforcement of Prop 65 is inconsistent.
- Companies may elect not to provide warnings because they conclude that they are not required to do so under Prop 65; a lack of warnings for a
  product does not mean that the product is free of listed chemicals at similar levels.

#### Why does Toro include this warning?

Toro has chosen to provide consumers with as much information as possible so that they can make informed decisions about the products they buy and use. Toro provides warnings in certain cases based on its knowledge of the presence of one or more listed chemicals without evaluating the level of exposure, as not all the listed chemicals provide exposure limit requirements. While the exposure from Toro products may be negligible or well within the "no significant risk" range, out of an abundance of caution, Toro has elected to provide the Prop 65 warnings. Moreover, if Toro does not provide these warnings, it could be sued by the State of California or by private parties seeking to enforce Prop 65 and subject to substantial penalties.



### Count on it.