



ASSEMBLY INSTRUCTIONS

Important Safety Instructions:






- Please read all instructions before beginning assembly.
- Please make sure receive all the parcels to start the assembly.
- For your safety and convenience, assembly by two people is recommended.
- Use the parts and hardware lists to identify and separate each of the components included.
- Save all packing materials until assembly is completed to avoid the accidental discarding of smaller parts of hardware.

Note: You may find cushions placed between frames!





Parts List:

NO.	Part	Qty	Image	NO.	Part	Qty	Image
①	Left arm	1		②	Right arm	1	
③	Chair back	1		④	Seat Panel	1	
⑤	Swing Bracket	1		⑥	Chair Base	1	
⑦	Seat Cushion	1		⑧	Back Cushion	1	
A	Screw (6x40mm)	12		C	Screw (6x20mm)	6	
N	NUT	8		S	Flat Washer	8	
L	Allen wrench	1		T	Open end Wrench	1	

WARNING:

- The chairs is not a toy.
- Please don't over-swing the chair, because it could possibly make the chair tip over and results in injury. Proper use of the chair is for single person seating only. Moreover, the chair is not to be used for standing purposes and it will not function as a stool or step-ladder. In addition, please use this chair on even surfaces only. Chair tested for use at a weight of 250lb.
- Any improper use of this product or failure to use as directed may result in injury.
- Please keep all children and pets away from the assembly area. In addition, children and pets should be supervised when they are in the area of product construction.
- Some parts may contain sharp edges. Therefore, when assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to the product. Please read all instructions before assembly and use.
- Please check all bolts for tightness before use. IMPORTANT-check and tighten bolts often to keep them secure!
- Please DO NOT put excessive weight on the product, this could cause damage to the side table.
- Not intended for commercial use.

CARE & MAINTENANCE


STAIN RESISTANT CUSHIONS CARE---KEEP THE CUSHIONS IN STORAGE IN RAINING DAY.

FABRIC CARE


Please use cold water and hand wash, use non-chlorine bleach when needed, lay flat to dry. Cool iron if necessary. Do not dry clean.

RESIN WICKER PRODUCT CARE

Before using, please clean the product completely with a soft dry towel. Moreover, when the chairs and table not in use, you should wipe off any dirt or lose objects, wash with a mild solution of soap and water, rinse thoroughly and dry completely. Please do not use strong detergent or abrasive cleaners. Since nuts and bolts can loosen over time, so please check nuts and bolt on all chairs and tables, re-tighten if necessary.




Step 6: Please verify the alignment and adjust, fully tighten all the screws now. Then put seat cushion (7) and back cushion (8) on the chair.




Step 7: Verify the alignment and adjust, make sure all screws are fully tightened. Now your chair is assembled.

Note: Do not tighten bolts until all parts are connected




Step 1: Insert seat panel (4) into the two holes on chair back (3), then secure them with 2 screws (C) by using allen wrench (L). Do not tighten all screws now.




Step 2: Secure left arm (1) to assembled chair back (3) with 2 screws (C) by using allen wrench (L). Do not tighten all screws now. Then, secure seat panel (4) to assembled left arm (1) with 2 screws (A) by using allen wrench (L). Do not fully tighten now.

Note: Do not tighten bolts until all parts are connected




Step 3: Secure right arm (2) to assembled chair back (3) with 2 screws (C) by using allen wrench (L). Then, secure seat panel (4) to assembled right arm (2) with 2 screws (A) by using allen wrench (L). Please tighten all screws now.



Step 4: Turn chair top upside down on carpet or padded surface and install the swing bracket (5) to bottom tube of the left arm (1) and right arm (2) by using 4 screws (A), 4 flat washers (S), 4 nuts (N), allen wrench (L), and open end wrench (T). PLEASE ATTACH TWO SCREWS IN DIAGONAL POSITION FIRST TO KEEP THE BALANCE, THEN INSTALL THE OTHER TWO SCREWS.

Note: Do not tighten bolts until all parts are connected



Step 5: Rotate the top plate on the chair base (6) into correct position, make sure it matches the holes on the swing bracket. Connect the 4 screws (A) through the holes of the plate on the base (6) and the holes on the tube of swing bracket (5) with 4 flat washers (S) and 4 nuts (N) by using allen washer (L) and open end wrench (T). NOTE: THIS STEP IS VERY IMPORTANT. DO READ THE INSTRUCTION AND DIAGRAM CAREFULLY.