

SPECIFICATION

Subject to change without prior notice.

Engine Type	Forced Air-cooled 2-Stroke
Displacement	43cc
Max. Output	1.1kW
Fuel	Gas/Oil Mixture (50:1)
Fuel Tank Capacity	27 ounces
Ignition System	C.D.I.
Starting System	Recoil
Gear Ratio	5:1
Max. Engine Speed	8500 r/min
Clutch Engine Speed	3700 r/min
Blade Speed	1200-1700 RPM
Spark plug type/ model	BM6A (Champion CJ8)

MAINTENANCE AND STORAGE

Air Filter

Never run engine without air cleaner properly installed. Added wear and engine failure may occur if air cleaner is not installed. Service air cleaner every 3 months or after 20 hours of operation. Clean filter daily in extremely dusty conditions

Steps for Cleaning Air Filter

Wash in warm water with mild soap until dirt and debris are removed. Press filter when washing, do not twist.

Rinse in warm water until soap and dirt are removed.

Dry filter by wrapping in a clean cloth and pressing filter until it is dry.

Apply oil to the entire filter.

Remove excess oil.

Attach the filter and air cleaner cover to the engine.